



# HYDRA-MATIC 6L80 (6 Speed)

## INDEX

|  |            |
|--|------------|
| <i>GENERAL DESCRIPTION AND OPERATION .....</i>                 | <i>4</i>   |
| <i>SHIFT QUADRANT DESCRIPTION .....</i>                        | <i>4</i>   |
| <i>INTERNAL COMPONENT LOCATION AND APPLICATION CHART.....</i>  | <i>6</i>   |
| <i>SOLENOID APPLICATION CHART .....</i>                        | <i>7</i>   |
| <i>ELECTRONIC COMPONENT LOCATIONS AND DESCRIPTION .....</i>    | <i>8</i>   |
| <i>PARTIAL WIRE SCHEMATIC .....</i>                            | <i>18</i>  |
| <i>DIAGNOSTIC TROUBLE CODE (DTC) IDENTIFICATION .....</i>      | <i>19</i>  |
| <i>CHECKBALL LOCATIONS AND FUNCTION .....</i>                  | <i>23</i>  |
| <i>OIL PASSAGE IDENTIFICATION .....</i>                        | <i>24</i>  |
| <i>IDENTIFICATION TAG LOCATION AND INFORMATION .....</i>       | <i>29</i>  |
| <i>TRANSMISSION FLUID REQUIREMENTS .....</i>                   | <i>29</i>  |
| <i>CONVERTER HOUSING IDENTIFICATION .....</i>                  | <i>30</i>  |
| <i>TRANSMISSION DISASSEMBLY .....</i>                          | <i>31</i>  |
| <i>COMPONENT REBUILD SECTION</i>                               |            |
| <i>TRANSMISSION CASE ASSEMBLY .....</i>                        | <i>39</i>  |
| <i>OIL PUMP ASSEMBLY .....</i>                                 | <i>41</i>  |
| <i>4-5-6 CLUTCH HOUSING ASSEMBLY .....</i>                     | <i>50</i>  |
| <i>1-2-3-4 AND 3-5 REVERSE CLUTCH HOUSING ASSEMBLY .....</i>   | <i>56</i>  |
| <i>CENTER SUPPORT ASSEMBLY .....</i>                           | <i>66</i>  |
| <i>LOW SPRAG ROTATION .....</i>                                | <i>69</i>  |
| <i>1-2-3-4 CLUTCH HUB AND SHAFT ASSEMBLY .....</i>             | <i>72</i>  |
| <i>2-6 AND 3-5 REVERSE CLUTCH HUB AND SHAFT ASSEMBLY .....</i> | <i>72</i>  |
| <i>REAR CARRIER AND OUTPUT SHAFT ASSEMBLY .....</i>            | <i>73</i>  |
| <i>VALVE BODY AND SOLENOID BODY/TCM ASSEMBLY .....</i>         | <i>81</i>  |
| <i>EXTENSION HOUSING ASSEMBLY .....</i>                        | <i>88</i>  |
| <i>TRANSMISSION FINAL ASSEMBLY .....</i>                       | <i>89</i>  |
| <i>BOLT CHART FOR IDENTIFICATION .....</i>                     | <i>101</i> |
| <i>SPECIAL TOOLS AND EQUIPMENT .....</i>                       | <i>102</i> |
| <i>GENERAL SPECIFICATIONS .....</i>                            | <i>106</i> |
| <i>LINE PRESSURE SPECIFICATIONS AND TAP LOCATION .....</i>     | <i>107</i> |
| <i>TORQUE SPECIFICATIONS .....</i>                             | <i>108</i> |

**AUTOMATIC TRANSMISSION SERVICE GROUP**  
**18639 S.W. 107 AVENUE**  
**MIAMI, FLORIDA 33157**  
**(305) 670-4161**

Copyright © ATSG 2007



# INTRODUCTION

## *6L80 (6 Speed)*

*1st Printing  
July, 2007*

The new Hydra-matic 6L80 (6 Speed) is a fully automatic, six speed, rear wheel drive, electronic controlled transmission that features clutch to clutch shifting. It was first introduced in the 2006 Corvette with the 6.0L engine, Cadillac STSV/XLRV with the 4.4L engine, and is scheduled for Pick-ups in 2007, as shown in Figure 1. It consists primarily of a four element torque converter, two planetary gear sets, five clutch packs, one sprag and a hydraulic pressurization and control system. Two planetary gear sets provide the six forward gear ratios and reverse. Changing gear ratios is fully automatic and is accomplished through the use of a Transmission Control Module (TCM), that is *located within the transmission*. The TCM receives and monitors various electronic sensor inputs, and uses this information to shift the transmission at the optimum time. The TCM commands shift solenoids and variable bleed Clutch Pressure Control (CPC) solenoids within the transmission to control shift timing. The TCM controls shift feel through the CPC solenoids. The TCM also controls the apply and release of the torque converter clutch which allows the engine to deliver the maximum fuel efficiency without sacrificing vehicle performance. This manual contains procedures necessary to diagnose, overhaul and/or repair the new 6L80 (6 Speed) transmission from General Motors.

No part of any ATSG publication may be reproduced, stored in any retrieval system or transmitted in any form or by any means, including but not limited to electronic, mechanical, photocopying, recording or otherwise, without *written* permission of Automatic Transmission Service Group. This includes all text illustrations, tables and charts.

*"Portions of materials contained herein have been reprinted under license from General Motors Corp, Service & Parts Operations License Agreement Number 0510718"*

*The information and part numbers contained in this booklet have been carefully compiled from industry sources known for their reliability, but ATSG does not guarantee its accuracy.*

*Copyright © ATSG 2007*

**WAYNE COLONNA**  
PRESIDENT

**DALE ENGLAND**  
FIELD SERVICE CONSULTANT

**PETER LUBAN**  
TECHNICAL CONSULTANT

**JON GLATSTEIN**  
TECHNICAL CONSULTANT

**ROLAND ALVAREZ**  
TECHNICAL CONSULTANT

**GERALD CAMPBELL**  
TECHNICAL CONSULTANT

**JIM DIAL**  
TECHNICAL CONSULTANT

**ED KRUSE**  
TECHNICAL CONSULTANT


**GREGORY LIPNICK**  
TECHNICAL CONSULTANT

**DAVID CHALKER**  
TECHNICAL CONSULTANT


**JERRY GOTT**  
TECHNICAL CONSULTANT

**MIKE SOUZA**  
TECHNICAL CONSULTANT

**AUTOMATIC TRANSMISSION SERVICE GROUP**  
**18639 S.W. 107 AVENUE**  
**MIAMI, FLORIDA 33157**  
**(305) 670-4161**



*Chevrolet And GMC  
4WD Version*



*Chevrolet  
Corvette Version*

Figure 1



# Technical Service Information

## GENERAL DESCRIPTION

The new Hydra-matic 6L80 (6 Speed) is a fully automatic, six speed, rear wheel drive, electronic controlled transmission that features clutch to clutch shifting. It consists primarily of a four element torque converter, two planetary gear sets, five clutch packs, one sprag and a hydraulic pressurization and control system.

The four element torque converter contains a pump, a turbine, a pressure plate splined to the turbine, and a stator assembly. The torque converter acts as a fluid coupling to smoothly transmit power from the engine to the transmission. It also hydraulically provides additional torque multiplication when required. The pressure plate, when applied, provides a mechanical "direct drive" coupling of the engine to the turbine shaft of the transmission.

The two planetary gear sets provide the six forward gear ratios and reverse. Changing gear ratios is fully automatic and is accomplished through the use of a Transmission Control Module (TCM) located within the transmission. The TCM receives and monitors various electronic sensor inputs, and uses this information to shift the transmission at the optimum time.

The TCM commands shift solenoids and variable bleed Clutch Pressure Control (CPC) solenoids within the transmission to control shift timing. The TCM controls shift feel through the CPC solenoids. The TCM also controls the apply and release of the torque converter clutch which allows the engine to deliver the maximum fuel efficiency without sacrificing vehicle performance.

The hydraulic system primarily consists of a vane type pump, two control valve bodies, converter housing and case. The pump maintains the working pressures needed to apply the clutch pistons that apply or release the friction components. These friction components, when applied or released, support the shifting qualities of the transmission.

The friction components used in this transmission consist of five multiple disc clutches. The multiple disc clutches combine with one mechanical sprag clutch, to deliver seven different gear ratios through the gearsets that then transfer torque through the output shaft. Refer to Figure 4 for the component application chart for this transmission.

## SHIFT QUADRANTS

The transmission shift quadrants vary by model. There may be four to seven different positions shown on the shift quadrants, as shown in Figure 2 and in Figure 3.

### Standard Shift Quadrant

**P** - Park position enables the engine to be started while preventing the vehicle from moving. For safety reasons, the vehicle's parking brake should always be used in addition to the "Park" position. Park position should not be selected until the vehicle has come to a complete stop.

**R** - Reverse enables the vehicle to be operated in a rearward direction.

**N** - Neutral position enables the engine to start and operate without driving the vehicle. If necessary, this position should be selected to restart the engine while the vehicle is moving.

**D** - Drive range should be used for all normal driving conditions for maximum efficiency and fuel economy. Drive range allows the transmission to operate in each of the six forward gear ratios. Downshifts to a lower gear are available for safe passing, by depressing the accelerator, or by manually selecting a lower gear with the shift lever.

### Manual Shift Ranges

*Some* vehicles are equipped with a shift quadrant that allow manual range selection. For example, "M" manual range and/or manual range "2" or "1", as shown in Figure 2. These ranges can be used for conditions where it may be desirable to control the selection of gear ratios. These conditions include trailer towing, driving on hilly terrain, and are also helpful for engine braking when descending slight grades.

**M** - When manual mode is selected, the current gear range will be the highest attainable range with all of the lower gears available. Plus/Minus buttons may be used to select the desired range of gears for the current driving conditions.

Continued on next Page

Copyright © 2007 ATSG




Figure 2

### Standard Shift Quadrant (Cont'd)

**2** - Manual 2nd just adds more performance for congested traffic and hilly terrain. It has the same starting ratio (1st gear) as the Drive range, but prevents the transmission from shifting above 2nd gear. Manual 2nd can be used to retain 2nd gear for acceleration and engine braking as desired. Manual 2nd can be selected at any vehicle speed, but will downshift into 2nd gear, only if vehicle speed is low enough not to over-rev the engine. This speed is calibrated in the TCM.

**1** - Manual 1st has the same starting ratio as Drive range but prevents the transmission from shifting above 1st gear. Manual 1st can be used for heavy towing and engine braking as desired. Manual 1st can be selected at any vehicle speed but will downshift into 1st gear, only if vehicle speed is low enough not to over-rev the engine. This speed is calibrated in the TCM.

### SHIFT QUADRANTS (CONT'D)

#### Driver Shift Control (DSC) Quadrant

Some vehicles are equipped with Driver Shift Control (DSC) version of the selector system, as shown in Figure 3. This configuration allows the driver to manually shift between forward gears.

**P** - Park position enables the engine to be started while preventing the vehicle from moving. For safety reasons, the vehicle's parking brake should always be used in addition to the "Park" position. Park position should not be selected until the vehicle has come to a complete stop.

#### Driver Shift Control (DSC) Quadrant (Cont'd)

**R** - Reverse enables the vehicle to be operated in a rearward direction.

**N** - Neutral position enables the engine to start and operate without driving the vehicle. If necessary, this position should be selected to restart the engine while the vehicle is moving.

**D** - Drive range should be used for all normal driving conditions for maximum efficiency and fuel economy. Drive range allows the transmission to upshift and downshift in each of the six forward gear ratios, according to the normal shift pattern that is programmed in the TCM.

**M/S** - In the M/S (Manual or Sport) position, the driver may manually select the range of gears by tapping the selector lever towards "+" or "-" to cause an upshift or downshift, as shown in Figure 3. The transmission will shift up or down depending on the request that is made by tapping the selector lever.





Figure 3

## INTERNAL COMPONENT IDENTIFICATION AND LOCATION



### COMPONENT APPLICATION CHART


| RANGE   | 1-2-3-4 Clutch | 3-5, Rev Clutch | 4-5-6 Clutch | 2-6 Clutch | Low & Rev Clutch | Low Sprag | Torg Conv Clutch | GEAR RATIO |
|---------|----------------|-----------------|--------------|------------|------------------|-----------|------------------|------------|
| Park    |                |                 |              |            | Applied          |           |                  |            |
| Reverse |                | Applied         |              |            | Applied          |           |                  | 3.06       |
| Neutral |                |                 |              |            | Applied          |           |                  |            |
| "D"-1st | Applied        |                 |              |            | Applied          | Holding   |                  | 4.03       |
| "D"-2nd | Applied        |                 |              | Applied    |                  |           | Applied*         | 2.36       |
| "D"-3rd | Applied        | Applied         |              |            |                  |           | Applied*         | 1.53       |
| "D"-4th | Applied        |                 | Applied      |            |                  |           | Applied*         | 1.15       |
| "D"-5th |                | Applied         | Applied      |            |                  |           | Applied*         | 0.85       |
| "D"-6th |                |                 | Applied      | Applied    |                  |           | Applied*         | 0.67       |
| "M"-2nd | Applied        |                 |              | Applied    |                  |           | Applied*         | 2.36       |
| "M"-1st | Applied        |                 |              |            | Applied          | Holding   |                  | 4.03       |

\* TCC IS AVAILABLE IN 2ND THRU 6TH GEAR, BASED ON THROTTLE POSITION, FLUID TEMP AND VEHICLE SPEED.

Copyright © 2007 ATSG

Figure 4

## CONTROL SOLENOID BODY AND TCM ASSEMBLY



### SOLENOID APPLICATION CHART

| RANGE          | Shift Sol. 1 | Shift Sol. 2 | CPC Sol. 5<br>1-2-3-4 CL.<br>(N.L.) | CPC Sol. 4<br>2-6 CL.<br>(N.L.) | CPC Sol. 2<br>3-5 Rev CL.<br>(N.H.) | CPC Sol. 3<br>4-5-6, Low/Rev CL.<br>(N.H.) | TCC PC Sol.<br>Torq Conv CL.<br>(N.L.) | LINE PC Sol.<br>Line Pres Cont<br>(N.H.) | GEAR RATIO |
|----------------|--------------|--------------|-------------------------------------|---------------------------------|-------------------------------------|--|--|--|------------|
| <b>Park</b>    | ON           | ON           | OFF                                 | OFF                             | ON                                  | OFF  | OFF                                    | ON**                                     |            |
| <b>Reverse</b> | ON           | OFF          | OFF                                 | OFF                             | OFF                                 | OFF  | OFF                                    | ON**                                     | 3.06       |
| <b>Neutral</b> | ON           | ON           | OFF                                 | OFF                             | ON                                  | OFF  | OFF                                    | ON**                                     |            |
| <b>"D"-1st</b> | ON           | ON           | ON                                  | OFF                             | ON                                  | ON   | OFF                                    | ON**                                     | 4.03       |
| <b>"D"-2nd</b> | OFF          | ON           | ON                                  | ON                              | ON                                  | ON   | ON*                                    | ON**                                     | 2.36       |
| <b>"D"-3rd</b> | OFF          | ON           | ON                                  | OFF                             | OFF                                 | ON   | ON*                                    | ON**                                     | 1.53       |
| <b>"D"-4th</b> | OFF          | ON           | ON                                  | OFF                             | ON                                  | OFF  | ON*                                    | ON**                                     | 1.15       |
| <b>"D"-5th</b> | OFF          | ON           | OFF                                 | OFF                             | OFF                                 | OFF  | ON*                                    | ON**                                     | 0.85       |
| <b>"D"-6th</b> | OFF          | ON           | OFF                                 | ON                              | ON                                  | OFF  | ON*                                    | ON**                                     | 0.67       |
| <b>"M"-2nd</b> | OFF          | ON           | ON                                  | ON                              | ON                                  | ON   | ON*                                    | ON**                                     | 2.36       |
| <b>"M"-1st</b> | ON           | ON           | ON                                  | OFF                             | ON                                  | OFF  | OFF                                    | ON**                                     | 4.03       |

FOR SHIFT SOLENOIDS 1 AND 2: "ON" = ENERGIZED (PRESSURIZED), "OFF" = DE-ENERGIZED (NO PRESSURE).  
 FOR CPC SOLENOIDS 2, 3: "ON" = NO PRESSURE, "OFF" = PRESSURIZED. FOR CPC SOLENOIDS 4, 5: "ON" = PRESSURIZED, "OFF" = NO PRESSURE.  
 \* TCC IS AVAILABLE IN 2ND THRU 6TH GEAR, BASED ON THROTTLE POSITION, FLUID TEMP AND VEHICLE SPEED.  
 \*\* CONSTANTLY VARIES LINE PRESSURE BASED ON THROTTLE POSITION, FLUID TEMP, AND GEAR STATE.

Figure 5

## ELECTRONIC COMPONENTS

In the 6L80 transmission, the TCM, both shift solenoids, all 6 of the pressure control solenoids, the TFT sensor and fluid pressure switches are contained in one unit, the Control Solenoid Body and TCM Assembly, which is located in the bottom pan, as shown in Figure 6.

Electrical signals from various sensors provide information to the TCM about vehicle speed, throttle position, engine coolant temp, fluid temp, range selector position, engine speed, turbine speed and operating mode. The TCM uses this information to determine the precise moment to upshift or downshift, apply or release the TCC, and

what pressure is needed to apply the clutches. This type of control provides consistent and precise shift points and shift quality based on the actual operating conditions of the vehicle.

Adaptive shift control technology enables the TCM to continually monitor and compare shift performance to the optimum shift, and make adjustments to the factory settings to continually deliver excellent shift quality.




Figure 6




Figure 7

## ***ELECTRONIC COMPONENTS (CONT'D)***

### ***Control Solenoid Body And TCM Assembly***

The Control Solenoid Body and TCM Assembly bolts directly to the lower and upper valve body assemblies inside the transmission. The solenoid assembly utilizes a lead frame system to connect the components to the TCM, as shown in Figure 7. There are no wires used for these components. The Control Solenoid Body and TCM Assembly connect to the external harness 16 way connector using a pass-thru sleeve. All fluid passages to the switches and solenoids are protected from debris by a serviceable filter plate assembly, as shown in Figure 7. In addition to the components shown in Figure 7, there are two temperature sensors located *inside* the TCM that are not shown, the TCM Temperature Sensor and the Power Up Temperature Sensor.

The components shown in Figure 7 are diagnosed separately, but serviced as an assembly.

### ***Transmission Fluid Temperature (TFT) Sensor***

The TFT sensor is part of the control solenoid body and TCM assembly, and is not serviced separately, as shown in Figure 7 and 8. The TFT sensor is a thermister, which changes value based on temperature. The sensor has a negative temperature coefficient, which means as the temp increases, the resistance decreases, and as the temp decreases, the resistance increases. The TCM supplies a voltage reference signal to the sensor and measures the voltage drop in the circuit. The TCM uses this information to maintain shift quality and torque converter clutch apply quality over the entire operating temperature range. If the TCM detects an improper signal from the TFT sensor, a DTC will be activated.

**Continued on next Page**




Figure 8

## ELECTRONIC COMPONENTS (CONT'D)

### Fluid Pressure Switches

The transmission fluid pressure switches located in the control solenoid body and TCM assembly are normally closed. When closed, these switches allow current flow through the switch. When fluid pressure is routed to the switch, pressure moves the diaphragm, piston and disk such that the circuit opens and there is no current flow. See Figure 9 for a cut-away view and a pressure switch logic chart.


TFP switch 1 sends a signal to the TCM to indicate the state of the 3-5 and reverse clutch Reg. valve.

TFP switch 3 sends a signal to the TCM to indicate the state of the 2-6 clutch regulator valve.

TFP switch 4 sends a signal to the TCM to indicate the state of the 1-2-3-4 clutch regulator valve.

TFP switch 5 sends a signal to the TCM to indicate the state of CBR1/4-5-6 clutch regulator valve. (CBR1 = Clutch Braking 1st)

***The fluid pressure switches are part of the Control Solenoid Body and TCM Assembly, and are not serviced seperately.***



### Pressure Switch Logic

| Selector Position | Switch 1 | Switch 3 | Switch 4 | Switch 5 |
|-------------------|----------|----------|----------|----------|
| Park              | 1        | 0        | 0        | 0        |
| Reverse           | 0        | 0        | 0        | 0        |
| Neutral           | 1        | 0        | 0        | 0        |
| "D"-1st           | 1        | 1        | 0        | 1        |
| "D"-2nd           | 1        | 0        | 0        | 1        |
| "D"-3rd           | 0        | 1        | 0        | 1        |
| "D"-4th           | 1        | 1        | 0        | 0        |
| "D"-5th           | 0        | 1        | 1        | 0        |
| "D"-6th           | 1        | 0        | 1        | 0        |
| "M"-1st           | 1        | 1        | 0        | 0        |

**1 = Pressurized Open)    0 = Exhausted (Closed)**

Figure 9

Continued on next Page

## **ELECTRONIC COMPONENTS (CONT'D)**

### **SHIFT SOLENOIDS 1 AND 2**

Shift solenoids 1 and 2 are both identical, normally closed, 3 port, ON/OFF type solenoids controlled by the TCM. These shift solenoids work in combination with the clutch pressure control solenoids to control the various shift and clutch regulator valves in the valve body.

When the TCM provides a path to ground for the electrical circuit to energize (Turn ON) the solenoid, current flows through the coil assembly in the solenoid and creates a magnetic field. The magnetic field moves the plunger and metering ball assembly to the right, as shown in Figure 10, against the exhaust seat, thereby blocking the exhaust passage and creating solenoid control pressure.

Shift solenoids are de-energized (Turned OFF) when the TCM opens the path to ground for the solenoid's electrical circuit. With the solenoid OFF, solenoid spring force moves the plunger and metering ball assembly to the left, as shown in Figure 10, away from the exhaust seat and against the feed seat. This blocks actuator feed limit fluid from entering the solenoid and allows any existing solenoid control pressure to exhaust through the solenoid.

***Shift Solenoids 1 and 2 are part of the Control Solenoid Body and TCM Assembly, and are not serviced separately.***

#### ***Shift Solenoid 1***

Actuator feed limit fluid feeds the shift solenoid 1 fluid circuit to control clutch select valve 2. When shift solenoid 1 is energized (ON), actuator feed limit fluid is allowed to pass through the solenoid, thereby creating solenoid 1 control pressure, as shown in Figure 10. Solenoid 1 control pressure acts against clutch select valve 2 spring force, to move the valve to the apply position.

When shift solenoid 1 is de-energized (OFF), actuator feed limit fluid is blocked from feeding the solenoid 1 circuit, and any existing solenoid 1 control pressure exhausts through the solenoid, as shown in Figure 10.




Figure 10

#### ***Shift Solenoid 2***

Actuator feed limit fluid feeds the shift solenoid 2 fluid circuit to control clutch select valve 3. When shift solenoid 1 is energized (ON), actuator feed limit fluid is allowed to pass through the solenoid, thereby creating solenoid 2 control pressure, as shown in Figure 10. Solenoid 2 control pressure acts against clutch select valve 3 spring force, to move the valve to the apply position.

When shift solenoid 2 is de-energized (OFF), actuator feed limit fluid is blocked from feeding the solenoid 2 circuit, and any existing solenoid 2 control pressure exhausts through the solenoid, as shown in Figure 10.

#### ***Fail-Safe or Protection Mode***

If for any reason, the entire electronic control system of the transmission, or any one of the electrical components within the Control Solenoid Body and TCM Assembly becomes disabled, the transmission will default to fail-safe mode. If the transmission is in 1st, 2nd or 3rd gear during an electrical failure, the transmission will default to 3rd gear. If the transmission is in 4th, 5th or 6th gear during an electrical failure, the transmission will default to 5th gear.

## **ELECTRONIC COMPONENTS (CONT'D)**

### **PRESSURE CONTROL SOLENOIDS**

#### **Line Pressure Control (PC) Solenoid**

The line pressure (PC) solenoid is a precision electronic pressure regulator that controls line pressure based on current flow through its coil windings. The TCM varies current to the "**normally-high**" line pressure control (PC) solenoid from approximately 0.1 amp (maximum line pressure), to 1.0 amps (minimum line pressure). As current flow is increased, the magnetic field produced by the coil moves the solenoid's variable restriction further away from the exhaust port, as shown in Figure 11. Opening the exhaust port decreases the control pressure, which is routed to the isolator (boost) valve, as shown in Figure 11, which ultimately decreases line pressure. As the current flow is decreased, the reduced magnetic field allows the spring force to move the variable restriction to the left, as shown in Figure 11, closer to the exhaust port, increasing control pressure from the solenoid, which ultimately increases line pressure.

As the throttle position (engine torque) increases, the current flow is decreased by the TCM, which increases the pressure output of the line pressure (PC) solenoid. If the TCM detects a line pressure control solenoid electrical malfunction, a DTC will be activated.

***The line pressure control (PC) solenoid is part of the Control Solenoid Body And TCM Assembly and is not serviced seperately.***

If for any reason, the entire electronic control system of the transmission fails, the line pressure control solenoid will be OFF, and maximum line pressure will be the result. This will create harsh engagements.




Figure 11

## **ELECTRONIC COMPONENTS (CONT'D)**

### **TORQUE CONVERTER CLUTCH (TCC) SOLENOID**

The Torque Converter Clutch (TCC) PC Solenoid is a "normally-low", electronic pressure regulator used to control the apply and release of the torque converter clutch based on current flow through its coil windings. The TCC PC solenoid regulates actuator feed limit fluid pressure to the TCC regulator valve, located in the lower valve body, and provides a signal pressure to shift the TCC control valve, located in the pump, to the apply position, as shown in Figure 12. When the TCM determines to apply the TCC, the TCC PC solenoid is commanded to specific pressures, dependent on vehicle operating conditions, resulting in a smooth apply or release of the TCC. The solenoid's ability to "Ramp" the TCC apply and release pressures result in a smoother TCC operation.

When vehicle operating conditions are appropriate to apply the TCC, the TCM increases current flow to allow the TCC PC solenoid to increase PCS TCC fluid pressure, to move the TCC control valve to the apply position, as shown in Figure 12, and move the TCC regulator valve to the regulating position to regulate fluid pressure proportional to solenoid pressure. Release pressure is directed to exhaust, and regulated apply pressure is directed to the apply

side of the converter clutch plate/damper assembly. The TCM then increases the pressure to control a slippage of 20-80 RPM between the clutch plate and converter cover. This "Ramping" procedure provides improved dampening of engine vibrations and allows the TCC to apply at low engine speeds in 2nd, 3rd, 4th, 5th and 6th gear.

Release of the TCC is achieved by decreasing TCC solenoid pressure to a level low enough to allow spring force to move the TCC control valve and TCC regulating valve to the release position.

There are also some operating conditions that may prevent or enable TCC apply, such as engine temp, transmission temperature, brake switch activation.

If the TCM detects that the TCC system is stuck ON or OFF, a DTC will be activated.

*The TCC PC Solenoid is part of the Control Solenoid Body And TCM Assembly and is not serviced separately.*




Figure 12

## **ELECTRONIC COMPONENTS (CONT'D)** **CLUTCH PRESSURE CONTROL (CPC)** **SOLENOIDS 2,3,4 AND 5**

There are two different types of clutch pressure control solenoids. Clutch pressure control (CPC) solenoids 2 and 3 are *"normally-high"* pressure control solenoids, as shown in Figure 14, and are identical to the line pressure control solenoid. Clutch pressure control (CPC) solenoids 4 and 5 are *"normally-low"* pressure control solenoids, as shown in Figure 13, and are identical to the TCC PC solenoid.

*The Clutch Pressure Control PC Solenoids are part of the Control Solenoid Body And TCM Assembly and are not serviced separately.*

### **Clutch Pressure Control Solenoid 2**

Clutch pressure control (CPC) solenoid 2 controls fluid flow to the 3-5/reverse clutch regulator valve and the 3-5/reverse boost valve. When commanded, the solenoid controls the flow of exhaust fluid out of the solenoid to maintain a specific commanded control pressure. This allows the TCM to control the apply and release of the 3-5 and reverse clutch.

### **Clutch Pressure Control Solenoid 3**

Clutch pressure control (CPC) solenoid 3 controls fluid flow to the 4-5-6 clutch regulator valve and the 4-5-6 boost valve. When commanded, the solenoid controls the flow of exhaust fluid out of the solenoid to maintain a specific commanded control pressure. This allows the TCM to control the apply and release of the 4-5-6 clutch.

### **Clutch Pressure Control Solenoid 4**

Clutch pressure control (CPC) solenoid 4 controls fluid flow to the 2-6 clutch regulator valve. When commanded, the solenoid controls the flow of exhaust fluid out of the solenoid to maintain a specific commanded control pressure. This allows the TCM to control the apply and release of the 2-6 clutch.

### **Clutch Pressure Control Solenoid 5**

Clutch pressure control (CPC) solenoid 5 controls fluid flow to the 1-2-3-4 clutch regulator valve and the 1-2-3-4 boost valve. When commanded, the solenoid controls the flow of exhaust fluid out of the solenoid to maintain a specific commanded control pressure. This allows the TCM to control the apply and release of the 1-2-3-4 clutch.




Figure 13




Figure 14

### **Transmission Adapt Function**

Programming within the TCM also allows for automatic adjustments in shift pressure that are based on the changing characteristics of the transmission components. As the apply components within the transmission wear or change over time, the time required to apply a clutch increases or decreases. In order to compensate for these changes, the TCM adjusts the pressure commands to the various pressure control solenoids, to maintain the original calibrations. The automatic adjusting process is referred to as "Adaptive Learning" and is used to ensure consistent shift feel and increase the transmission's durability.

## ELECTRONIC COMPONENTS (CONT'D)

### TRANSMISSION MANUAL SHIFT

#### POSITION SWITCH ASSEMBLY

The Transmission Manual Shift Position Switch Assembly, sometimes referred to as Internal Mode Switch (IMS), is a sliding contact switch that connects to the manual valve, with a connector that plugs into the control solenoid body and TCM assembly, and is shown in Figure 16.

There are four inputs to the TCM from the position switch assembly, that indicate which transmission gear range has been selected. The state of each input is available for display on the scan tool. The four input parameters represented are Signal A, Signal B, Signal C, and Signal P (Parity).

A fifth input signal "N" (P/N Start), does not input to the TCM, but goes directly to the ECM to determine a Park/Neutral state and allow the engine to be started. Routing Signal N to the ECM will allow the engine to be started, even with a dead TCM. Signal N is not a signal used by the TCM for manual shift selector position logic. A logic chart has been provided for you in Figure 15, and a partial wire schematic in Figure 17.

The Transmission Manual Shift Position Switch assembly is serviced separately.

If the TCM detects an improper signal from the transmission manual shift position switch (IMS) assembly, a DTC will be activated.

| <b>INTERNAL MODE SWITCH LOGIC</b> |                 |                 |                 |                 |
|-----------------------------------|-----------------|-----------------|-----------------|-----------------|
| <i>Gear Selector Position</i>     | <i>Signal A</i> | <i>Signal B</i> | <i>Signal C</i> | <i>Signal P</i> |
| <i>Park</i>                       | <i>LOW</i>      | <i>HI</i>       | <i>HI</i>       | <i>LOW</i>      |
| <i>Park/Reverse</i>               | <i>LOW</i>      | <i>LOW</i>      | <i>HI</i>       | <i>LOW</i>      |
| <i>Reverse</i>                    | <i>LOW</i>      | <i>LOW</i>      | <i>HI</i>       | <i>HI</i>       |
| <i>Reverse/Neutral</i>            | <i>HI</i>       | <i>LOW</i>      | <i>HI</i>       | <i>HI</i>       |
| <i>Neutral</i>                    | <i>HI</i>       | <i>LOW</i>      | <i>HI</i>       | <i>LOW</i>      |
| <i>Neutral/Drive 6</i>            | <i>HI</i>       | <i>LOW</i>      | <i>LOW</i>      | <i>LOW</i>      |
| <i>Drive 6</i>                    | <i>HI</i>       | <i>LOW</i>      | <i>LOW</i>      | <i>HI</i>       |
| <i>Drive 6/Drive 4</i>            | <i>LOW</i>      | <i>LOW</i>      | <i>LOW</i>      | <i>HI</i>       |
| <i>Drive 4</i>                    | <i>LOW</i>      | <i>LOW</i>      | <i>LOW</i>      | <i>LOW</i>      |
| <i>Drive 4/Drive 3</i>            | <i>LOW</i>      | <i>HI</i>       | <i>LOW</i>      | <i>LOW</i>      |
| <i>Drive 3</i>                    | <i>LOW</i>      | <i>HI</i>       | <i>LOW</i>      | <i>HI</i>       |
| <i>Drive 3/Drive 2</i>            | <i>HI</i>       | <i>HI</i>       | <i>LOW</i>      | <i>HI</i>       |
| <i>Drive 2</i>                    | <i>HI</i>       | <i>HI</i>       | <i>LOW</i>      | <i>LOW</i>      |
| <i>Open</i>                       | <i>HI</i>       | <i>HI</i>       | <i>HI</i>       | <i>HI</i>       |
| <i>Invalid</i>                    | <i>HI</i>       | <i>HI</i>       | <i>HI</i>       | <i>LOW</i>      |
| <i>Invalid</i>                    | <i>LOW</i>      | <i>LOW</i>      | <i>LOW</i>      | <i>HI</i>       |

*HI = Ignition Voltage*  
*LOW = 0 Volts*

Copyright © 2007 ATSG

| <i>Internal Mode Switch Terminal Identification</i> |  |
|---|--|
| <i>Terminal</i>                                     | <i>Function</i>                                      |
| <i>A</i>  | <i>Park/Neutral Start Signal "N" (Direct to ECM)</i> |
| <i>B</i>  | <i>Mode Switch Switch Signal "A"</i>                 |
| <i>C</i>  | <i>Mode Switch Switch Signal "B"</i>                 |
| <i>D</i>  | <i>Mode Switch Switch Signal "C"</i>                 |
| <i>E</i>  | <i>Mode Switch Switch Signal "P"</i>                 |
| <i>F</i>  | <i>Ignition Switch Voltage Feed</i>                  |

Figure 15




Figure 16




Figure 17

## **ELECTRONIC COMPONENTS (CONT'D)** **TRANSMISSION SPEED SENSORS**

The speed sensors are both 2 wire hall-effect type sensors which bolt to the valve body assembly and connect to the control solenoid body and TCM assembly through a wire harness and connector, as shown in Figure 17 and 18.

If the TCM detects an improper signal from the input or output speed sensors, a DTC will be activated.

### **Input Speed Sensor Assembly**

The input speed sensor faces the 1-2-3-4 and 3-5-R clutch housing and is triggered by splines on the housing outside diameter. The sensor receives 8.3-9.3 volts from the TCM, and produces a signal frequency based on the spline profile and rotation speed of the 1-2-3-4 clutch housing. The TCM uses this signal to determine line pressure, shift timing, TCC slip speed and gear ratio.

### **Output Speed Sensor Assembly**

The output speed sensor faces the output shaft housing and is triggered by slots in the housing outside diameter. The sensor receives 8.3-9.3 volts from the TCM, and produces a signal frequency based on the machined slots and rotation speed of the output shaft housing. The TCM uses this signal to determine line pressure, shift timing, vehicle speed and gear ratio.





Figure 18

## 16-WAY CASE CONNECTOR TERMINAL IDENTIFICATION



View Looking Into  
16-Way Case  
Connector

| Pin No. | Function                 |
|---------|--------------------------|
| 1       | Not Used                 |
| 2       | Not Used                 |
| 3       | Park/Neutral Signal      |
| 4       | Battery Voltage Feed     |
| 5       | Ground                   |
| 6       | Brake Pedal Apply Signal |
| 7       | Tap Up/Tap Down Switch   |
| 8       | Not Used                 |
| 9       | Accessory Voltage Power  |
| 10      | CAN Hi                   |
| 11      | CAN Lo                   |
| 12      | Run/Crank Voltage Power  |
| 13      | CAN Lo 2                 |
| 14      | CAN Hi 2                 |
| 15      | Replicated OSS Signal    |
| 16      | Not Used                 |

Copyright © 2007 ATSG

Figure 19


## ELECTRONIC COMPONENTS (CONT'D)

### 16-Way Case Connector

The 16-way transmission case connector is also part of the control solenoid body and TCM assembly, as shown in Figure 20, and *is not* serviced separately. The case connector and the terminal identification chart are both illustrated in Figure 19, for diagnostic purposes. We have also provided a full wiring schematic in Figure 21.

Since the case connector is part of the TCM and is located internally, there is an additional sleeve with "O" rings and a seal required to seal the passage in the case, as shown in Figure 20. Once the control solenoid body and TCM assembly has been installed onto the valve body, you must pull the retaining tab down, as shown in Figure 20, install the pass through sleeve with the "O" rings and seal, and then press the retaining tab back up engaging the tab into the pass through sleeve.

### TRANSMISSION CASE TO TCM SLEEVE ASSEMBLY



- 1 16-WAY TRANSMISSION CASE CONNECTOR.
- 2 TCM ASSEMBLY TO TRANSMISSION CASE SLEEVE SEAL.
- 3 CASE SLEEVE TO TRANSMISSION CASE "O" RING SEALS (2).
- 4 TRANSMISSION CASE SLEEVE ASSEMBLY.
- 5 TRANSMISSION CASE SLEEVE RETAINING TAB.

Copyright © 2007 ATSG

Figure 20




Figure 21



## Technical Service Information

| <b>DIAGNOSTIC TROUBLE CODE (DTC) IDENTIFICATION</b> |   |                  |
|---|---|------------------|
| <b>DTC</b>  | <b>DESCRIPTION</b>  | <b>DTC TYPE*</b> |
| P0218   | <i>Transmission Fluid Overtemperature, Over 270°F for 10 minutes.</i>     | A                |
| P0562   | <i>System Voltage Low, 11 volts or less for 10 seconds.</i>               | A                |
| P0563   | <i>System Voltage High, Greater than 18 volts for 12 seconds.</i>         | A                |
| P0601   | <i>TCM (Internal), Read Only Memory (ROM).</i>                            | A                |
| P0602   | <i>TCM, Not Programmed.</i>   | A                |
| P0603   | <i>TCM (Internal), Long term memory reset.</i>                            | A                |
| P0604   | <i>TCM (Internal), Random Access Memory (RAM).</i>                        | A                |
| P0634   | <i>TCM (Internal), Overtemperature.</i>                                   | A                |
| P0667   | <i>TCM (Internal), Temperature Sensor Performance.</i>                    | A                |
| P0668   | <i>TCM (Internal), Temperature Sensor circuit voltage low.</i>            | A                |
| P0669   | <i>TCM (Internal), Temperature Sensor circuit voltage high.</i>           | A                |
| P0703   | <i>Brake Switch Circuit, signal is invalid for 4 seconds.</i>             | A                |
| P0711   | <i>Transmission Fluid Temperature (TFT), Sensor performance.</i>          | C                |
| P0712   | <i>Transmission Fluid Temperature (TFT), Sensor circuit voltage low.</i>  | A                |
| P0713   | <i>Transmission Fluid Temperature (TFT), Sensor circuit voltage high.</i> | A                |
| P0716   | <i>Input Speed Sensor (ISS), Sensor performance.</i>                      | A                |
| P0717   | <i>Input Speed Sensor (ISS), Sensor circuit voltage low.</i>              | A                |
| P0719   | <i>Brake Switch Circuit, Circuit voltage low.</i>                         | A                |
| P0722   | <i>Output Speed Sensor (OSS), Sensor circuit voltage low.</i>             | C                |
| P0723   | <i>Output Speed Sensor (OSS), Sensor intermittent.</i>                    | B                |
| P0724   | <i>Brake Switch Circuit, Circuit voltage high.</i>                        | A                |
| P0729   | <i>Incorrect 6th Gear Ratio.</i>  | C                |
| P0731   | <i>Incorrect 1st Gear Ratio.</i>  | A                |
| P0732   | <i>Incorrect 2nd Gear Ratio.</i>  | A                |
| P0733   | <i>Incorrect 3rd Gear Ratio.</i>  | A                |
| P0734   | <i>Incorrect 4th Gear Ratio.</i>  | A                |
| P0735   | <i>Incorrect 5th Gear Ratio.</i>  | A                |
| P0736   | <i>Incorrect Reverse Gear Ratio.</i>                                      | A                |
| P0741   | <i>Torque Converter Clutch (TCC), System Stuck OFF.</i>                   | A                |
| P0742   | <i>Torque Converter Clutch (TCC), System Stuck ON.</i>                    | B                |
| P0751   | <i>Shift Solenoid (SS) 1 Valve Performance, Stuck OFF.</i>                | B                |
| P0752   | <i>Shift Solenoid (SS) 1 Valve Performance, Stuck ON.</i>                 | A                |

\*DTC TYPES  
A - Emission-related, turns the MIL "ON" immediately after the 1st failure.  
B - Emission-related, turns the MIL "ON" after two consecutive drive cycles with failure.  
C - Non-emission-related, no lamps and may display message on driver information center.

Copyright © 2007 ATSG

Figure 22



## Technical Service Information

| <b>DIAGNOSTIC TROUBLE CODE (DTC) IDENTIFICATION</b>  |  |                  |
|--|--|------------------|
| <b>DTC</b>   | <b>DESCRIPTION</b>   | <b>DTC TYPE*</b> |
| P0776  | <i>Clutch Pressure Control (CPC) Solenoid 2, Stuck OFF.</i>              | A                |
| P0777  | <i>Clutch Pressure Control (CPC) Solenoid 2, Stuck ON.</i>               | A                |
| P0796  | <i>Clutch Pressure Control (CPC) Solenoid 3, Stuck OFF.</i>              | A                |
| P0797  | <i>Clutch Pressure Control (CPC) Solenoid 3, Stuck ON.</i>               | A                |
| P0815  | <i>Upshift Switch Circuit Error.</i>                                     | C                |
| P0816  | <i>Downshift Switch Circuit Error.</i>                                   | C                |
| P0826  | <i>Upshift and Downshift Switch Circuit Error.</i>                       | C                |
| P0842  | <i>Transmission Fluid Pressure (TFP) Switch 1, Circuit Voltage Low.</i>  | C                |
| P0843  | <i>Transmission Fluid Pressure (TFP) Switch 1, Circuit Voltage High.</i> | C                |
| P0851  | <i>Park/Neutral Position (PNP) Switch, Circuit Voltage Low.</i>          | C                |
| P0852  | <i>Park/Neutral Position (PNP) Switch, Circuit Voltage High.</i>         | C                |
| P0872  | <i>Transmission Fluid Pressure (TFP) Switch 3, Circuit Voltage Low.</i>  | C                |
| P0873  | <i>Transmission Fluid Pressure (TFP) Switch 3, Circuit Voltage High.</i> | C                |
| P0877  | <i>Transmission Fluid Pressure (TFP) Switch 4, Circuit Voltage Low.</i>  | C                |
| P0878  | <i>Transmission Fluid Pressure (TFP) Switch 4, Circuit Voltage High.</i> | C                |
| P0961  | <i>Line Pressure Control (PC) Solenoid, System Performance.</i>          | A                |
| P0962  | <i>Line Pressure Control (PC) Solenoid, Circuit Voltage Low.</i>         | A                |
| P0963  | <i>Line Pressure Control (PC) Solenoid, Circuit Voltage High.</i>        | A                |
| P0965  | <i>Clutch Pressure Control (CPC) Solenoid 2, System Performance.</i>     | A                |
| P0966  | <i>Clutch Pressure Control (CPC) Solenoid 2, Circuit Voltage Low.</i>    | A                |
| P0967  | <i>Clutch Pressure Control (CPC) Solenoid 2, Circuit Voltage High.</i>   | A                |
| P0969  | <i>Clutch Pressure Control (CPC) Solenoid 3, System Performance.</i>     | A                |
| P0970  | <i>Clutch Pressure Control (CPC) Solenoid 3, Circuit Voltage Low.</i>    | A                |
| P0971  | <i>Clutch Pressure Control (CPC) Solenoid 3, Circuit Voltage High.</i>   | A                |
| P0973  | <i>Shift Solenoid 1 (SS), Control Circuit Voltage Low.</i>               | A                |
| P0974  | <i>Shift Solenoid 1 (SS), Control Circuit Voltage High.</i>              | A                |
| P0976  | <i>Shift Solenoid 2 (SS), Control Circuit Voltage Low.</i>               | A                |
| P0977  | <i>Shift Solenoid 2 (SS), Control Circuit Voltage High.</i>              | A                |
| P0989  | <i>Transmission Fluid Pressure (TFP) Switch 5, Circuit Voltage Low.</i>  | C                |
| P0990  | <i>Transmission Fluid Pressure (TFP) Switch 5, Circuit Voltage High.</i> | C                |
| P1621  | <i>TCM (Internal), Long Term Memory Performance.</i>                     | A                |
| P1684  | <i>TCM (Internal), Power Up Temperature Sensor Performance.</i>          | A                |
| <p><b>*DTC TYPES</b><br/>           A - Emission-related, turns the MIL "ON" immediately after the 1st failure.<br/>           B - Emission-related, turns the MIL "ON" after two consecutive drive cycles with failure.<br/>           C - Non-emission-related, no lamps and may display message on driver information center.</p> |  |                  |

Copyright © 2007 ATSG

Figure 23



# Technical Service Information

| <b>DIAGNOSTIC TROUBLE CODE (DTC) IDENTIFICATION</b>  |   |                  |
|--|---|------------------|
| <b>DTC</b>   | <b>DESCRIPTION</b>  | <b>DTC TYPE*</b> |
| P1685  | <i>TCM (Internal), Power Up Temperature Sensor, Circuit Voltage Low.</i>                  | A                |
| P1686  | <i>TCM (Internal), Power Up Temperature Sensor, Circuit Voltage High.</i>                 | A                |
| P1751  | <i>Shift Valve 1, Performance of Clutch Select Valve 2.</i>                               | A                |
| P1825  | <i>Internal Mode Switch, Invalid Range</i>  | A                |
| P1831  | <i>TCM (Internal), Driver No. 2, (Controls Line Pressure &amp; Shift Lock Solenoids).</i> | A                |
| P1832  | <i>TCM (Internal), Driver No. 2, (Controls Line Pressure &amp; Shift Lock Solenoids).</i> | C                |
| P1876  | <i>Up and Down Shift Switch Performance, Range Switch Not In D3.</i>                      | C                |
| P1915  | <i>Internal Mode Switch, Start In Wrong Range.</i>  | A                |
| P2534  | <i>Ignition Switch, Start Circuit Voltage Low.</i>  | A                |
| P2714  | <i>Clutch Pressure Control (CPC) Solenoid 4, Stuck OFF.</i>                               | A                |
| P2715  | <i>Clutch Pressure Control (CPC) Solenoid 4, Stuck ON.</i>                                | A                |
| P2719  | <i>Clutch Pressure Control (CPC) Solenoid 4, System Performance.</i>                      | A                |
| P2720  | <i>Clutch Pressure Control (CPC) Solenoid 4, Circuit Voltage Low.</i>                     | A                |
| P2721  | <i>Clutch Pressure Control (CPC) Solenoid 4, Circuit Voltage High.</i>                    | A                |
| P2723  | <i>Clutch Pressure Control (CPC) Solenoid 5, Stuck OFF.</i>                               | A                |
| P2724  | <i>Clutch Pressure Control (CPC) Solenoid 5, Stuck ON.</i>                                | A                |
| P2728  | <i>Clutch Pressure Control (CPC) Solenoid 5, System Performance.</i>                      | A                |
| P2729  | <i>Clutch Pressure Control (CPC) Solenoid 5, Circuit Voltage Low.</i>                     | A                |
| P2730  | <i>Clutch Pressure Control (CPC) Solenoid 5, Circuit Voltage High.</i>                    | A                |
| P2762  | <i>TCC Pressure Control (PC) Solenoid, System Performance.</i>                            | A                |
| P2763  | <i>TCC Pressure Control (PC) Solenoid, Circuit Voltage High.</i>                          | A                |
| P2764  | <i>TCC Pressure Control (PC) Solenoid, Circuit Voltage Low.</i>                           | A                |
| *DTC TYPES<br>A - Emission-related, turns the MIL "ON" immediately after the 1st failure.<br>B - Emission-related, turns the MIL "ON" after two consecutive drive cycles with failure.<br>C - Non-emission-related, no lamps and may display message on driver information center. |   |                  |

Copyright © 2007 ATSG

Figure 24

## **FAIL-SAFE OR PROTECTION MODE**

If for any reason, the entire electronic control system of the transmission, or any one of the electrical components within the Control Solenoid Body and TCM Assembly becomes disabled, the transmission will default to fail-safe mode. If the transmission is in 1st, 2nd or 3rd gear during an electrical failure, the transmission will default to 3rd gear. If the transmission is in 4th, 5th or 6th gear during an electrical failure, the transmission will default to 5th gear.

If for any reason, the entire electronic control system of the transmission fails, the line pressure control solenoid will be OFF, and maximum line pressure will be the result. This will create harsh engagements. The TCC PC solenoid would also be OFF, resulting in no torque converter clutch apply.



# Technical Service Information

## **6L80 CHECKBALL LOCATION AND FUNCTION**

### ***Number 1 Checkball***

The number one checkball is located in the upper valve body, as shown in Figure 25. When the transmission is operating in Drive 1st, 2nd, 3rd, 4th, 5th or 6th gear, drive 1-6 fluid seats the checkball against the drive braking passage and enters the 2-6 clutch/1-2-3-4 clutch feed circuit to apply the 1-2-3-4 clutch.

### ***Number 2 Checkball***

The number two checkball is located in the upper valve body, as shown in Figure 25. This shuttle type checkball is seated against the reverse passage while the transmission is operating in Park, Neutral and Drive 1st. With the checkball in this position, shift solenoid 1 fluid enters the CSV2 enable circuit to the "clutch select valve 2". When the transmission is operating in Reverse, the checkball seats against shift solenoid 1 passage to allow reverse fluid to enter the CSV2 enable circuit and hold the "clutch select valve 2" in the applied position.

### ***Number 3 Checkball***

The number three checkball is located in the upper valve body, as shown in Figure 25. This shuttle type checkball is seated against the 4-5-6 clutch passage while the transmission is operating in Park, Reverse, Neutral, Drive 1st, 2nd and 3rd gear. With the checkball in this position, shift solenoid 2 fluid enters the CSV3 enable circuit to apply the "clutch select valve 3". When the transmission is operating in Drive 4th, 5th or 6th gear, the checkball seats against the shift solenoid 2 passage to allow 4-5-6 clutch fluid to enter the CSV3 enable circuit and hold the "clutch select valve 3" in the applied position.

### ***Number 4 Checkball***

The number four checkball is located in the upper valve body, as shown in Figure 25. This shuttle type checkball is seated against the 4-5-6 clutch passage by Pressure Solenoid 5 fluid, while the transmission is operating in Park, Reverse, Neutral, Drive 1st, 2nd and 3rd gear. With the checkball in this position, PS 5 fluid enters the CSV2 latch circuit to hold the "clutch select valve 2" in the released position. When the transmission is operating in Drive 4th, 5th or 6th gear, 4-5-6 clutch fluid seats the checkball against the PS 5 passage to allow 4-5-6 clutch fluid to enter the CSV2 latch circuit to hold the "clutch select valve 2" in released the position.

### ***Number 5 Checkball***

The number five checkball is located in the upper valve body, as shown in Figure 25. This shuttle type checkball is seated against the Drive 1-6 passage by 3-5/Reverse Feed fluid while the transmission is operating in Reverse. With the checkball in this position, 3-5/Reverse Feed fluid enters the 3-5/Reverse Supply circuit and is routed to the number 7 checkball. When the transmission is operating in Drive 1st, 2nd, 3rd, 4th, 5th or 6th gear, Drive 1-6 fluid seats the ball against the 3-5/Reverse Feed passage to allow Drive 1-6 fluid to enter the 3-5/Reverse Supply circuit.



### ***Number 6 Checkball***

The number six checkball is located in the upper valve body, as shown in Figure 25. This "one way orifice control" type checkball is used to differentiate the flow rate of fluid between applying and releasing the 1-2-3-4 clutch. 2-6 clutch/1-2-3-4 clutch feed fluid opens the checkball, while the transmission is operating in Drive 1st, 2nd, 3rd, 4th, 5th or 6th gear. With the ball in this position, 2-6 clutch/1-2-3-4 clutch feed fluid flows freely into the 1-2-3-4 clutch feed passage. When Park, Reverse or Neutral is selected after the transmission was operating in Drive, exhausting 1-2-3-4 clutch feed fluid seats the checkball, and forces exhausting fluid through orifice number 32, which allows for a controlled exhaust of the 1-2-3-4 clutch.

### ***Number 7 Checkball***

The number seven checkball is located in the upper valve body, as shown in Figure 25. This "one way orifice control" type checkball is used to differentiate the flow rate of fluid between applying and releasing the 3-5/Reverse clutch. 3-5/Reverse Supply fluid pressure seats the checkball against the 3-5/Reverse Feed passage, while the transmission is operating in Reverse, Drive 1st, 2nd, 3rd, 4th, 5th or 6th gear. With the checkball in this position, 3-5/Reverse Supply fluid is forced through orifice number 25 before entering the 3-5/Reverse Feed passage. The orifice helps control the apply rate of the 3-5/Reverse clutch when the transmission shifts into Reverse, 3rd or 5th gear. When Park or Neutral is selected after the transmission was operating in Drive, or Reverse, exhausting 3-5/Reverse Feed fluid unseats the checkball. This allows for a faster exhaust of 3-5/Reverse Feed fluid and a quick release of the 3-5/Reverse clutch.

## 6L80 CHECKBALL LOCATION AND FUNCTION




Copyright © 2007 ATSG

Figure 25


## LOWER VALVE BODY, SPACER PLATE SIDE

See Figure 28 For Legend



## LOWER VALVE BODY, TCM/SOLENOID BODY SIDE

See Figure 28 For Legend




Copyright © 2007 ATSG

Figure 26


## UPPER VALVE BODY, SPACER PLATE SIDE

See Figure 28 For Legend



## UPPER VALVE BODY, CASE SIDE

See Figure 28 For Legend



Copyright © 2007 ATSG


Figure 27

## PASSAGE IDENTIFICATION LEGEND

- |  |  |
|--|--|
| 1 SUCTION                              | 30 CBR (Clutch Braking)                        |
| 2 LINE                                 | 31 CBR1/4-5-6 CLUTCH FEED                      |
| 3 DECREASE                             | 32 CBR1 FEEDBACK                               |
| 4 CONVERTER FEED                       | 33 4-5-6 CLUTCH FEED                           |
| 5 CONVERTER FEED LIMIT                 | 34 4-5-6 CLUTCH                                |
| 6 TCC RELEASE                          | 35 CSV2 LATCH                                  |
| 7 TCC APPLY                            | 36 DRIVE B                                     |
| 8 COOLER FEED                          | 37 3-5/REVERSE FEED                            |
| 9 CENTER LUBE                          | 38 PCS TCC (Pressure Control Solenoid)         |
| 10 REGULATOR APPLY                     | 39 PCS 1234 CLUTCH (Pressure Control Solenoid) |
| 11 COMPENSATOR FEED                    | 40 PCS 4 (Pressure Control Solenoid)           |
| 12 ACTUATOR FEED LIMIT                 | 41 PCS 2                                       |
| 13 REVERSE                             | 42 PCS 3                                       |
| 14 3-5/REVERSE CLUTCH                  | 43 PCS 5                                       |
| 15 3-5/REVERSE CLUTCH FEEDBACK         | 44 2-6 CLUTCH/1-2-3-4 CLUTCH FEED              |
| 16 CSV2 ENABLE (Clutch Select Valve 2) | 45 PCS 3-5/REVERSE CLUTCH                      |
| 17 SHIFT SOLENOID 1                    | 46 2-6 CLUTCH                                  |
| 18 SHIFT SOLENOID 2                    | 47 PCS 2-6 CLUTCH                              |
| 19 CSV3 ENABLE (Clutch Select Valve 3) | 48 PCS CBR1/4-5-6 CLUTCH                       |
| 20 DRIVE                               | 49 PCS LINE                                    |
| 21 DRIVE 1-6                           | 50 EXHAUST BACKFILL                            |
| 22 DRIVE BRAKE                         | 51 EXHAUST                                     |
| 23 1-2-3-4 CLUTCH DEFAULT FEED         | 52 VOID  |
| 24 1-2-3-4 CLUTCH DEFAULT              | 53 3-5/REVERSE SUPPLY                          |
| 25 1-2-3-4 CLUTCH FEED                 | 54 3-5/REVERSE CLUTCH FEED                     |
| 26 1-2-3-4 CLUTCH                      | 55 VENT  |
| 27 1-2-3-4 CLUTCH FEEDBACK             | 56 CONVERTER SEAL DRAINBACK                    |
| 28 CBR1/CBR FEED (Clutch Braking 1st)  | 57 FRONT LUBE                                  |
| 29 CBR1 (Clutch Braking 1st)           |  |

Copyright © 2007 ATSG

Figure 28



Copyright © 2007 ATSG


Figure 29

## PASSAGE IDENTIFICATION LEGEND

- |  |  |
|--|--|
| 1 SUCTION                              | 30 CBR (Clutch Braking)                        |
| 2 LINE                                 | 31 CBR1/4-5-6 CLUTCH FEED                      |
| 3 DECREASE                             | 32 CBR1 FEEDBACK                               |
| 4 CONVERTER FEED                       | 33 4-5-6 CLUTCH FEED                           |
| 5 CONVERTER FEED LIMIT                 | 34 4-5-6 CLUTCH                                |
| 6 TCC RELEASE                          | 35 CSV2 LATCH                                  |
| 7 TCC APPLY                            | 36 DRIVE B                                     |
| 8 COOLER FEED                          | 37 3-5/REVERSE FEED                            |
| 9 CENTER LUBE                          | 38 PCS TCC (Pressure Control Solenoid)         |
| 10 REGULATOR APPLY                     | 39 PCS 1234 CLUTCH (Pressure Control Solenoid) |
| 11 COMPENSATOR FEED                    | 40 PCS 4 (Pressure Control Solenoid)           |
| 12 ACTUATOR FEED LIMIT                 | 41 PCS 2                                       |
| 13 REVERSE                             | 42 PCS 3                                       |
| 14 3-5/REVERSE CLUTCH                  | 43 PCS 5                                       |
| 15 3-5/REVERSE CLUTCH FEEDBACK         | 44 2-6 CLUTCH/1-2-3-4 CLUTCH FEED              |
| 16 CSV2 ENABLE (Clutch Select Valve 2) | 45 PCS 3-5/REVERSE CLUTCH                      |
| 17 SHIFT SOLENOID 1                    | 46 2-6 CLUTCH                                  |
| 18 SHIFT SOLENOID 2                    | 47 PCS 2-6 CLUTCH                              |
| 19 CSV3 ENABLE (Clutch Select Valve 3) | 48 PCS CBR1/4-5-6 CLUTCH                       |
| 20 DRIVE                               | 49 PCS LINE                                    |
| 21 DRIVE 1-6                           | 50 EXHAUST BACKFILL                            |
| 22 DRIVE BRAKE                         | 51 EXHAUST                                     |
| 23 1-2-3-4 CLUTCH DEFAULT FEED         | 52 VOID  |
| 24 1-2-3-4 CLUTCH DEFAULT              | 53 3-5/REVERSE SUPPLY                          |
| 25 1-2-3-4 CLUTCH FEED                 | 54 3-5/REVERSE CLUTCH FEED                     |
| 26 1-2-3-4 CLUTCH                      | 55 VENT  |
| 27 1-2-3-4 CLUTCH FEEDBACK             | 56 CONVERTER SEAL DRAINBACK                    |
| 28 CBR1/CBR FEED (Clutch Braking 1st)  | 57 FRONT LUBE                                  |
| 29 CBR1 (Clutch Braking 1st)           |  |

Copyright © 2007 ATSG

Figure 30



Copyright © 2007 ATSG

Figure 31




Figure 32




Figure 33




Figure 34

| <b>DEXRON VI®</b> | <b>TRANSMISSION FLUID REQUIREMENTS</b>               | <b>DEXRON VI®</b> |
|-------------------|--|-------------------|
|                   | Pan Removal - Approximate Capacity                   | 6.5 Quarts        |
|                   | Overhaul - Approximate Capacity (Cadillac STSV/XLRV) | 10 Quarts         |
|                   | Overhaul - Approximate Capacity (Corvette)           | 12.5 Quarts       |

Copyright © 2007 ATSG

Figure 35

## BELL HOUSING IDENTIFICATION

There are currently three different bell housing configurations, as shown in Figure 36. The first is the Corvette version, in which the transmission is mounted in the rear of the vehicle, as it was with the 4L60E, and requires the torque tube from the engine to the rear of the vehicle. The second is the Cadillac STSV/XLRV version with the 4.4L engine, as shown in Figure 36. The third is the standard Chevrolet bell scheduled for trucks in 2007, as shown in Figure 36.

The converter housing also contains the pocket for the 13 vane rotor and slide assembly, with the pump cover bolting onto the back side of the converter housing, as shown in Figure 36. All three of the converter housings bolt to a 6L80 case and the 13 vane rotor and slide are common parts. The pump cover is also common, except for the calibration differences between the different 6L80 models.

*This manual will use the Corvette version to illustrate and reference all procedures.*




Figure 36




Figure 37

## **TRANSMISSION DISASSEMBLY**

### **EXTERNAL PARTS**

1. Remove the torque converter, as shown in Figure 37.
2. Install holding fixture J-8763-B, as shown in Figure 37, using fixture adapter DT-47605 if necessary and is shown in place in Figure 38.
3. Rotate transmission in fixture so that converter housing is facing up and secure with locking pin in fixture base.
4. Allow any remaining transmission fluid to drain from the extension housing.
5. Rotate transmission so that bottom pan is facing up as shown in Figure 39.

Continued on Page 32




Figure 38

## EXTERNAL PARTS (CONT'D)

6. Remove the six extension housing retaining bolts, as shown in Figure 39, and remove the extension housing.
 

*Note: Corvette version is illustrated.*
7. The two wheel drive version is also shown in Figure 39.
8. Remove the oil pan bolts, oil pan, oil pan gasket and oil filter, as shown in Figure 40.
 

*Note: Pan gasket is reusable if not damaged.*
9. Lift up on the electrical connector slide-lock, as shown in Figure 40, to remove the electrical connector.
 

*Note: Special Tool is available to remove the electrical connector and prevent any damage.*
10. Remove electrical connector by pulling straight out. Damage will result to the connector pins if any twisting motion is used.
11. Remove and discard the electrical connector seal and "O" rings as shown in Figure 40.




Figure 39

Continued on Page 33




Figure 40




Figure 41

### EXTERNAL PARTS (CONT'D)

12. Do not remove all the valve body assembly bolts. Remove only the bolts indicated in Figure 41.
  13. Remove the valve body assembly, as shown in Figure 42.
- Note: Use care when handling the valve body as it also includes the TCM/Solenoid body.*
14. Remove and discard the valve body to pump seals and the valve body to center support seal, as shown in Figure 42.
  15. Set the valve body assembly aside for the component rebuild section.

Continued on Page 34





Figure 42

## TRANSMISSION DISASSEMBLY

### INTERNAL PARTS


1. Rotate the transmission so that the converter housing is facing up, as shown in Figure 44.
  2. Remove the "O" ring from the turbine shaft, as shown in Figure 43.
  3. Remove the nine converter housing to case bolts, as shown in Figure 44.
- Note: There are no washers on these bolts.**
4. Remove the converter housing and oil pump assembly, as shown in Figure 44.
  5. Remove and discard the converter housing to case "O" ring seal, as shown in Figure 44.
  6. Set the converter housing/oil pump assembly aside for component rebuild section.

Continued on Page 35



Copyright © 2007 ATSG

Figure 43



- 2 CONVERTER HOUSING AND OIL PUMP ASSEMBLY
- 3 CONVERTER HOUSING TO CASE BOLTS (9 REQUIRED)
- 5 CONVERTER HOUSING TO CASE "O" RING SEAL
- 7 TRANSMISSION CASE ASSEMBLY

Copyright © 2007 ATSG

Figure 44

## INTERNAL PARTS (CONT'D)

7. Remove the 4-5-6 Clutch Housing and the 3-5 Reverse Clutch drum as a complete assembly by lifting straight up using the turbine shaft, as shown in Figure 45.
8. Separate all components removed, as shown in Figure 46, and set aside for component rebuild section.
9. Remove the 4-5-6 clutch hub and dampener assembly and thrust bearing, as shown in Figure 47.
10. Set the 4-5-6 clutch hub and the dampener assembly aside for component rebuild section.
11. Remove both clutch hub and shaft assemblies, all 3 bearings, as shown in Figure 48, and set aside for the component rebuild section.

Continued on Page 36




Figure 45




Figure 46




Figure 47

## INTERNAL PARTS (CONT'D)

12. Remove the center support snap ring using the J-45126 snap ring pliers along with DT-47773 adapter set, as shown in Figure 49.

**Caution:** This is a mandatory tool for snap ring removal to prevent bodily injury. Do not try to remove this snap ring with prying tools.

13. Remove the center support assembly, as shown in Figure 50, and set aside for the component rebuild section.

Continued on Page 37




Figure 48




Figure 49




Figure 50

## INTERNAL PARTS (CONT'D)

14. Remove the output carrier and output shaft assembly using the DT-47786 lifting tool, as shown in Figure 51.
15. Ensure the lifting tool is fully threaded into the output shaft assembly. Due to the weight of the assembly, incomplete threading may cause the assembly to break free from lifting tool, causing component damage or bodily injury.
16. Set output carrier and output shaft assembly aside for the component rebuild section.
17. Remove and discard the rear case seal, as shown in Figure 52.
18. Use care so as not to damage the case or the rear case bushing.

Continued on Page 39




Figure 51





Figure 52

## CASE AND RELATED PARTS EXPLODED VIEW



- 12 PARK PAWL SHAFT CASE PLUG
- 13 OUTPUT SHAFT CASE BUSHING
- 14 OUTPUT SHAFT CASE SEAL ASSEMBLY
- 500 PARK PAWL SHAFT
- 501 PARK PAWL SPRING (NOT SERVICED)
- 502 PARK PAWL (NOT SERVICED)
- 503 PARK PAWL ACTUATOR ASSEMBLY
- 504 MANUAL SHAFT DETENT LEVER RETAINING PIN
- 505 MANUAL SHAFT DETENT LEVER ASSEMBLY

- 506 MANUAL SHAFT RETAINING PIN
- 507 MANUAL SHAFT SEAL
- 508 MANUAL SHAFT
- 509 PARK PAWL ACTUATOR GUIDE
- 510 PARK PAWL ACTUATOR GUIDE "O" RING SEALS (2)
- 511 PARK PAWL ACTUATOR GUIDE RETAINING PIN

Copyright © 2007 ATSG

Figure 53

## COMPONENT REBUILD

### TRANSMISSION CASE ASSEMBLY

1. Clean the transmission case thoroughly and dry with compressed air.
2. Inspect the transmission case thoroughly for any wear or damage in the following areas:
  - *Front Case Sealing surfaces*
  - *Center Support Passage Seal Bores*
  - *Oil Pan Gasket Sealing Surface*
  - *Rear Case Plugs In Place*
  - *Rear Case Bushing*
  - *Fill Tube Bore*
  - *Electrical Connector Sleeve Bore*
  - *All Threaded Holes*

3. Remove the manual shaft from the case using Figure 53 as a guide, as the roll pins must be removed.

4. Remove and discard the manual shaft seal, as shown in Figure 55.

**Note:** *The special tool for the cooler line seal removal can also be used on the manual shaft seal for removal (See Figure 54).*

5. Install a new manual shaft seal using the proper installation tool, as shown in Figure 55, and ensure that it is fully seated in the bore.
6. Reinstall the manual shaft and the roll pins, using Figure 53 as a guide.

Continued on Page 40




Figure 54




Figure 55

Copyright © 2007 ATSG

## COMPONENT REBUILD

### TRANSMISSION CASE ASSEMBLY (CONT'D)

7. Remove park pawl actuator guide retaining pin and actuator guide, as shown in Figure 56.
8. Remove and discard the park pawl actuator guide "O" rings.
9. Install new park pawl actuator guide "O" rings and lube with a small amount of Trans-Jel®.
10. Install the park pawl actuator guide, as shown in Figure 56, ensuring you do not damage the "O" ring seals.
11. Install the actuator guide retaining pin into the case, as shown in Figure 56.
12. Install new rear case seal using seal installer, as shown in Figure 57.
13. Install new case plugs as necessary, as shown in Figure 58.

**Component Rebuild  
Continued on Page 41**




Figure 57




Figure 56




Figure 58

## OIL PUMP ASSEMBLY

1. Clean the converter housing and oil pump thoroughly before disassembly to remove any large particles of dirt or debris.

2. All of the components shown in the exploded view in Figure 59 will not be disassembled during the rebuild process.

Continued on Page 42




Figure 59

## OIL PUMP ASSEMBLY (CONT'D)

3. Remove the 13 oil pump cover to converter housing bolts, as shown in Figure 60, and remove the oil pump cover assembly.  
**Caution: "Do Not" remove the 6 bolts holding the stator shaft to the pump cover assembly. These bolts have been installed and torqued after specific clutch support rotational requirements (centered) have been met.**
4. Set oil pump cover and stator shaft assembly aside for now.
5. Disassemble the rotor, vanes, and slide from the converter housing, as shown in Figure 61.
6. Remove and discard the pump slide "O" ring (210) and slide seals (213 & 214), as shown in Figure 61.

Continued on Page 43




Figure 60




Figure 61

## OIL PUMP ASSEMBLY (CONT'D)

7. Remove the oil pump cover thrust washer.
8. Remove and discard the three sealing rings from the oil pump cover.
9. Disassemble the pump cover assembly using Figure 62 as a guide.
10. Lay each valve line-up out in order as you remove them from the oil pump cover.
11. Inspect each valve, valve spring and retainer for any wear and/or damage.
12. Clean all oil pump cover parts thoroughly and dry with compressed air.
13. Install each valve train back into their bores *exactly* as shown in Figure 62.  
**Note: Lubricate each valve train with a small amount of transmission fluid.**
14. Be sure to install the locating dowel, as shown in Figure 62, if you removed it.

15. Install the oil pump cover thrust washer, as shown in Figure 63, and ensure it is fully seated in the thrust washer tab bores.
16. Install three new "lap joint" sealing rings, as shown in Figure 63.
17. Lubricate sealing rings and thrust washer with a small amount of transmission fluid, and set pump cover assembly aside for now.  
**Note: Filter seal can be installed now, or wait until the pump cover has been installed onto the converter housing.**

Continued on Page 44




Figure 62

## OIL PUMP ASSEMBLY (CONT'D)

18. Place the converter housing on a flat surface with worm track surface facing up, as shown in Figure 64.
  19. Ensure that all slide seals are left out.
  20. Lay a straight edge across the surface over the slide and rotor, as shown in Figure 65.
  21. Measure the clearance between the slide and the straight edge, as shown in Figure 65. The clearance should be .001"-.002" with no seals in the slide.
  22. Measure the clearance between the rotor and the straight edge, as shown in Figure 65. The clearance should be .001"-.0015"
- Note: These measurements may also be done with a depth micrometer.*
23. If replacements are needed, use the chart in Figure 66 to make your selections based on the clearance recorded and the thickness of the current slide and rotor.

Continued on Page 45




Figure 64




Figure 63





Figure 65

## OIL PUMP ASSEMBLY (CONT'D)

24. Install new bushing as necessary in converter housing, as shown in Figure 67, using proper size bushing driver.
  25. Install new converter housing seal using the proper size seal installer (See Figure 67).
  26. Install the seal retaining snap ring, as shown in Figure 67, and ensure it is fully seated.
27. Install new cooler line seals into the converter housing, as shown in Figure 68, using the proper seal driver.


Continued on Page 46



| PUMP POCKET DEPTH   |                |                 |
|---------------------|----------------|-----------------|
| SIZE CLASSIFICATION | THICKNESS (MM) | THICKNESS (IN)  |
| 1                   | 17.980-17.994  | .7079" - .7084" |
| 2                   | 17.994-18.007  | .7084" - .7089" |
| 3                   | 18.007-18.003  | .7089" - .7100" |
| ROTOR SELECTION     | THICKNESS (MM) | THICKNESS (IN)  |
| 1                   | 17.948-17.961  | .7066" - .7071" |
| 2                   | 17.961-17.974  | .7071" - .7076" |
| 3                   | 17.974-17.987  | .7076" - .7081" |
| SLIDE SELECTION     | THICKNESS (MM) | THICKNESS (IN)  |
| 1                   | 17.948-17.961  | .7066" - .7071" |
| 2                   | 17.961-17.974  | .7071" - .7076" |
| 3                   | 17.974-17.987  | .7076" - .7081" |


Copyright © 2007 ATSG

Figure 66



Copyright © 2007 ATSG

Figure 67



Copyright © 2007 ATSG

Figure 68

## OIL PUMP ASSEMBLY (CONT'D)

28. Install the pump slide pivot pin and spring, as shown in Figure 69.
29. Install oil pump slide back-up "O" ring (210) and pump slide seal ring (209) into groove in pump slide, as shown in Figure 69, and retain with a small amount of Trans-Jel®.
30. Install the oil pump slide into the pump pocket, as shown in Figure 69, with the seal ring (209) facing down.

31. Install the oil pump slide "Teflon" seal (213) by pulling the slide toward the pump pivot pin and sliding the seal down between the slide seal support (214) and converter housing, as shown in Figure 69.
32. Install the oil pump slide spring, as shown in Figure 69, using a screwdriver or installation tool.
33. Install the oil pump rotor guide into the rotor in the direction shown in Figure 70, and retain with a small amount of Trans-Jel®.

**Note:** Align the rotor guide tabs to notches on the bottom of rotor (See Figure 70).

Continued on Page 47




Figure 69




Figure 70

## OIL PUMP ASSEMBLY (CONT'D)

34. Install one of the oil pump vane rings into the pump pocket, as shown in Figure 71.
35. Install the previously assembled rotor guide and rotor assembly into the pump pocket and ensure that it is properly seated.
36. Install the 13 oil pump vanes into their slots in the rotor, as shown in Figure 71.
37. Install the other oil pump vane ring on top of the rotor and inside of the oil pump vanes. The finished assembly should look like illustration in Figure 72.

**Note:** Lubricate rotor, vanes and slide with Dexron VI® fluid to prime the oil pump assembly.

38. Install the pre-assembled oil pump cover onto the converter housing, as shown in Figure 72.  
**Note:** Install the filter seal if not done previously in pump cover sub-assembly.
39. Install the oil pump cover to converter housing retaining bolts in their proper locations, as shown in Figure 72, and "hand tighten" only.

Continued on Page 48




Figure 71




Figure 72

## OIL PUMP ASSEMBLY (CONT'D)

40. Install the J-46664 pump alignment band and tighten, as shown in Figure 73.

**Note: This is a mandatory tool.**

41. Torque the 13 oil pump cover retaining bolts to 11 Nm (97 in.lb.), as shown in Figure 73, and using the sequence shown in Figure 74.

42. Remove J-46664 pump alignment band.

43. Place the completed converter housing and oil pump assembly aside for final assembly. (See Figure 75).




Figure 74




Figure 73






Figure 75

## 4-5-6 CLUTCH HOUSING EXPLODED VIEW



- 431 4-5-6 CLUTCH BACKING PLATE SNAP RING
- 432 4-5-6 CLUTCH BACKING PLATE
- 433 4-5-6 CLUTCH FRICTION PLATES
- 434 4-5-6 CLUTCH STEEL PLATES
- 435 4-5-6 CLUTCH "WAVED" PLATE
- 436 4-5-6 CLUTCH BALANCE PISTON SNAP RING
- 437 4-5-6 CLUTCH BALANCE PISTON
- 438 4-5-6 CLUTCH APPLY PISTON "BELLVILLE" RETURN SPRING
- 439 4-5-6 CLUTCH APPLY PISTON
- 440 4-5-6 CLUTCH HOUSING BUSHING (OUTPUT SHAFT)
- 441 4-5-6 CLUTCH HOUSING ASSEMBLY
- 442 TURBINE SHAFT SEALING RINGS (SOLID TEFLON)
- 443 TURBINE SHAFT "O" RING SEAL (CONVERTER CLUTCH)



Copyright © 2007 ATSG

Figure 76

## COMPONENT REBUILD


### 4-5-6 CLUTCH HOUSING ASSEMBLY

1. Disassemble the 4-5-6 clutch housing using Figure 76 as a guide.  
*Note: Use care when compressing the return spring. Compressing the balance piston too far may create damage to the piston.*
2. Remove and discard the 4-5-6 clutch balance piston snap ring.
3. Clean all 4-5-6 clutch housing parts thoroughly and dry with compressed air.
4. Inspect all 4-5-6 clutch housing parts for any wear and/or damage.
5. Replace the 4-5-6 clutch housing bushing as necessary (See Figure 77)
6. Lubricate a new 4-5-6 clutch piston with small amount of Trans-Jel® on both seal surfaces and install it into housing as shown in Figure 77, using a twisting motion.
7. Install the 4-5-6 clutch apply piston "bellville" type return spring, as shown in Figure 77, with the fingers facing up.
8. Lubricate a new 4-5-6 clutch balance piston with a small amount of Trans-Jel® on both of the seal surfaces and install into apply piston, as shown in Figure 77, with a twisting motion.
9. Compress the balance piston and return spring and install a *new* snap ring.  
*Note: Use care when compressing the return spring. Compressing the balance piston too far may create damage to the piston.*
10. Remove the spring compressor.

**Special Note:** ATSG recommends replacing all of the molded pistons, regardless of their condition.

**Special Note:** ATSG recommends pre-soaking the clutch pack friction plates in Dexron VI® for at least 30 minutes before assembly. This includes "All" clutch packs in this unit.

Continued on Page 51



- 436 4-5-6 CLUTCH BALANCE PISTON SNAP RING
- 437 4-5-6 CLUTCH BALANCE PISTON
- 438 4-5-6 CLUTCH APPLY PISTON "BELLVILLE" RETURN SPRING
- 439 4-5-6 CLUTCH APPLY PISTON
- 440 4-5-6 CLUTCH HOUSING BUSHING (OUTPUT SHAFT)
- 441 4-5-6 CLUTCH HOUSING ASSEMBLY

Copyright © 2007 ATSG

Figure 77

## 4-5-6 CLUTCH HOUSING ASSEMBLY

11. Install the 4-5-6 clutch "wave" plate, as shown in Figure 78.
12. Install the 4-5-6 clutch plates beginning with a steel plate and alternating with friction plate until you have installed 6 of each, as shown in Figure 78.
13. Install the 4-5-6 clutch backing plate, as shown in Figure 78.
14. Install the 4-5-6 clutch backing plate selective snap ring, as shown in Figure 78.
15. Install and zero dial indicator on 4-5-6 clutch housing, as shown in Figure 79.
16. While one finger blocks top passage in turbine shaft, apply regulated air to the opposite top hole and observe dial indicator reading, as shown in Figure 79.
17. Change the selective snap ring as necessary, to get 1.28-1.89mm (.050" - .074"), using the chart in Figure 80

Continued on Page 52




Figure 78




Figure 79

## 4-5-6 CLUTCH HOUSING ASSEMBLY (CONT'D)

18. Cut off and discard the three "Teflon" sealing rings on the turbine shaft (See Figure 82).
19. Install three new turbine shaft sealing rings as shown in Figure 82, using the installation tools shown in Figure 81.
20. Adjust the turn screw on the DT-47768-1 and install the bottom seal ring first.
21. After all three rings are installed, place the resizing tool over the three seals, as shown in Figure 83, and set aside for final assembly.

**Componet Rebuild**  
Continued on Page 53

| <i>Thickness</i>                   | <i>Color I.D.</i> |
|------------------------------------|-------------------|
| <i>1.60-1.70mm (.063" - .067")</i> | <i>Yellow</i>     |
| <i>2.02-2.12mm (.080" - .083")</i> | <i>None</i>       |
| <i>2.44-2.54mm (.096" - .100")</i> | <i>Purple</i>     |

Copyright © 2007 ATSG

Figure 80




Figure 82




Figure 81




Figure 83

## 4-5-6 CLUTCH DAMPENER ASSEMBLY

1. Disassemble the 4-5-6 clutch dampener using Figure 84 as a guide.
2. Thoroughly clean and inspect all 4-5-6 parts and dry with compressed air.
3. Install the 4-5-6 dampener into the 4-5-6 clutch hub in the direction shown in Figure 85, with smooth side of dampener material facing up.
4. Install the dampener apply plate in the direction shown in Figure 85.
5. Install the 4-5-6 clutch dampener snap ring, as shown in Figure 85, and ensure snap ring is fully seated.
6. Set the 4-5-6 clutch dampener assembly aside for final assembly (See Figure 86).




Figure 84




Figure 85




Figure 86

## 1-2-3-4 AND 3-5 REVERSE CLUTCH HOUSING EXPLODED VIEW





Figure 87

## 1-2-3-4 AND 3-5 REVERSE CLUTCH HOUSING EXPLODED VIEW



- 400 3-5 REVERSE CLUTCH BACKING PLATE SNAP RING
- 401 3-5 REVERSE CLUTCH BACKING PLATE
- 402 3-5 REVERSE CLUTCH FRICTION PLATES
- 403 3-5 REVERSE CLUTCH STEEL PLATES
- 404 3-5 REVERSE CLUTCH "WAVED" PLATE
- 405 3-5 REVERSE CLUTCH APPLY RING
- 407 1-2-3-4 CLUTCH BACKING PLATE
- 408 1-2-3-4 CLUTCH FRICTION PLATES
- 409 1-2-3-4 CLUTCH STEEL PLATES
- 410 1-2-3-4 CLUTCH "WAVED" PLATE
- 411 1-2-3-4 CLUTCH BALANCE PISTON SNAP RING
- 412 1-2-3-4 CLUTCH BALANCE PISTON
- 413 1-2-3-4 CLUTCH APPLY PISTON "BELLVILLE" RETURN SPRING
- 414 1-2-3-4 CLUTCH APPLY PISTON
- 415 1-2-3-4 CLUTCH PISTON HOUSING SNAP RING
- 416 1-2-3-4 CLUTCH APPLY PISTON SEAL

- 417 1-2-3-4 CLUTCH APPLY PISTON HOUSING
- 418 3-5 REVERSE CLUTCH PISTON DAM SEAL
- 419 3-5 REVERSE CLUTCH PISTON INNER SEAL (1ST DESIGN)
- 420 3-5 REVERSE CLUTCH APPLY PISTON "BELLVILLE" SPRING
- 421 3-5 REVERSE CLUTCH APPLY PISTON
- 422 3-5 REVERSE CLUTCH PISTON OUTER SEAL
- 423 1-2-3-4 CLUTCH PISTON INNER SEAL
- 424 1-2-3-4 CLUTCH PISTON HOUSING SEAL
- 425 1-2-3-4 CLUTCH PISTON HOUSING SEAL
- 426 3-5 REVERSE CLUTCH HOUSING REAR BUSHING
- 427 3-5 REVERSE CLUTCH HOUSING ASSEMBLY
- 428 3-5 REVERSE CLUTCH HOUSING BEARING ASSEMBLY
- 429 1-2-3-4 CLUTCH BACKING PLATE SNAP RING

Copyright © 2007 ATSG

Figure 88

## COMPONENT REBUILD

### 1-2-3-4 AND 3-5 REVERSE HOUSING

1. Disassemble the 1-2-3-4 and 3-5 reverse clutch housing using Figure 87 and 88 as a guide.
2. Remove and discard all rubber piston seals and "O" rings (See Figure 87 and 88).
3. Clean all 1-2-3-4 and 3-5 reverse clutch parts thoroughly and dry with compressed air.
4. Inspect all 1-2-3-4 and 3-5 reverse clutch parts for any wear and/or damage.
5. Remove and discard the caged roller bearing with the puller shown in Figure 89.

**Note:** *General Motors recommends this bearing be replaced on all rebuilds because of the incorporated lip seal (See Figure 90).*

6. Install a new caged roller bearing, as shown in Figure 90, with seal side facing up.
7. Install new bushing as necessary using proper bushing driver, as shown in Figure 91.

Continued on Page 57




Figure 90




Figure 89




Figure 91

## 1-2-3-4 AND 3-5 REVERSE HOUSING (CONT'D)

8. Install the seals into the grooves of 3-5 reverse clutch apply piston and 1-2-3-4 clutch apply piston, with the small lips facing towards the groove, as shown in Figure 92.




Figure 92

## CAUTION -- CAUTION -- CAUTION

For 2006 & 2007 "Transmission" Model Years, 6L80 units will be built with a 1st Design 3-5 Reverse Piston, and its corresponding 1st Design Inner Seal.

For the 2008 "Transmission" Model Year, 6L80 units will be built with a 2nd Design (Smaller) 3-5 Reverse Piston, and its corresponding 2nd Design Inner Seal.

Dimensional differences between 1st and 2nd Design pistons and seals, make them non-interchangeable. Each Design Level 3-5 Reverse Piston Inner Seal "MUST" be installed only with its corresponding Design Level 3-5 Reverse Piston. Refer to Figure 93 for the dimensions of the critical matching parts.




Figure 93

## 1-2-3-4 AND 3-5 REVERSE HOUSING (CONT'D)

9. Install only the two "O" ring seals into their grooves in the 1-2-3-4 and 3-5 reverse housing hub, as shown in Figure 94.

**Note: "Do Not" install the 1-2-3-4 clutch inner seal in the top groove at this time. We will install this seal "After" we have installed the snap ring for the 3-5 reverse piston.**




Figure 94

10. Lubricate the outer seal and both inner seal surfaces of the 3-5 reverse piston assembly, as shown in Figure 95.

Continued on Page 59




Figure 95

## 1-2-3-4 AND 3-5 REVERSE HOUSING (CONT'D)

11. Install the 3-5 reverse clutch apply piston into the 3-5 reverse clutch housing, as shown in Figure 95.
12. Install the 3-5 reverse clutch "bellville" return spring, as shown in Figure 95.
13. Lubricate all three seals on the 1-2-3-4 clutch piston housing, as shown in Figure 95.
14. Install the 1-2-3-4 clutch piston housing, as shown in Figure 95.
15. Before using the snap ring installer, push the snap ring over the cone by hand, so that the snap ring is positioned below the tapered area, as shown in Figure 96.
16. Push the snap ring down over the cone until it seats firmly in the snap ring groove. The snap ring will make a distinctive "click" sound when it seats.
17. Remove the snap ring installer and cone.
18. **Now**, install the 1-2-3-4 clutch piston inner seal with the lips facing the groove, as shown in Figure 97.
19. Install the 1-2-3-4 clutch apply piston into the housing, as shown in Figure 97.
20. Install the 1-2-3-4 clutch "bellville" return spring in direction shown in Figure 97.

Continued on Page 60





Figure 96



- 411 1-2-3-4 CLUTCH BALANCE PISTON SNAP RING
  - 412 1-2-3-4 CLUTCH BALANCE PISTON
  - 413 1-2-3-4 CLUTCH APPLY PISTON "BELLVILLE" RETURN SPRING
  - 414 1-2-3-4 CLUTCH APPLY PISTON
  - 423 1-2-3-4 CLUTCH PISTON INNER SEAL
  - 427 3-5 REVERSE CLUTCH HOUSING ASSEMBLY
- Copyright © 2007 ATSG

Figure 97





Figure 98

### 1-2-3-4 AND 3-5 REVERSE HOUSING (CONT'D)

21. Lubricate the seal area and install the 1-2-3-4 clutch balance piston, as shown in Figure 97.
22. Compress the assembly and install the snap ring, as shown in Figure 97.  
*Note: Compressing the balance piston too far may damage the piston, so use care.*
23. Install the 1-2-3-4 clutch "wave" plate into the housing, as shown in Figure 98.
24. Install the 1-2-3-4 clutch plates beginning with a steel plate and alternating with a friction until you have installed five of each, as shown in Figure 98.
25. Install the 1-2-3-4 clutch backing plate, as shown in Figure 98.
26. Install the 1-2-3-4 clutch backing plate snap ring, as shown in Figure 98.
27. Check 1-2-3-4 clutch clearance using a feeler gage between the snap ring and backing plate, as shown in Figure 99.
28. Change the selective snap ring to achieve the proper clutch clearance using thickness chart and both are found in Figure 99.

Continued on Page 61



*1-2-3-4 Clutch Clearance Should Be  
 1.53-1.99mm (.060" - .078")*

| THICKNESS                   | O.D. COLOR |
|-----------------------------|------------|
| 2.15-2.25mm (.085" - .089") | YELLOW     |
| 2.42-2.52mm (.095" - .099") | NONE       |
| 2.69-2.79mm (.106" - .110") | PURPLE     |
| 2.96-3.06mm (.117" - .120") | LIGHT BLUE |
| 3.23-3.33mm (.127" - .131") | ORANGE     |

Copyright © 2007 ATSG

Figure 99

## 1-2-3-4 AND 3-5 REVERSE HOUSING (CONT'D)

29. Install the 3-5 reverse clutch apply ring with legs going down between the 1-2-3-4 backing plate and the housing, as shown in Figure 100.
  30. Install the 3-5 reverse clutch "wave" plate on top of the apply ring, as shown in Figure 101.
  31. Install the 3-5 reverse clutch plates beginning with a steel plate and alternating with a friction plate until you have installed four of each, as shown in Figure 101.
  32. Install the 3-5 reverse clutch backing plate, as shown in Figure 101.
  33. Install the 3-5 reverse clutch backing plate selective snap ring, as shown in Figure 101.
- Note:** The snap ring opening must be aligned with the missing snap ring groove punch in the housing, as shown in Figure 102.

Continued on Page 62




Figure 100




Figure 101




Figure 102

### 1-2-3-4 AND 3-5 REVERSE HOUSING (CONT'D)

34. Check the 3-5 reverse clutch clearance using a feeler gage between the snap ring and backing plate, as shown in Figure 103.
35. The 3-5 reverse clutch clearance should be 1.21-1.79mm (.048" - .070").
36. Change the selective snap ring as necessary using the chart in Figure 103 to obtain correct clutch clearance.
37. Set the completed 1-2-3-4 and 3-5 reverse clutch housing aside for final assembly. (See Figure 104).

**Component Rebuild  
Continued on Page 64**




Figure 103





Figure 104



*ATSG BULLETINS  
AND MANUALS ON CD*



*THE BEST THING NEXT TO YOUR TOOL BOX  
IS A COMPLETE LIBRARY OF TECH AT YOUR  
FINGER TIPS...*



*THE TECH YOU NEED...  
WHEN YOU NEED IT FAST...*

**FOR MORE INFORMATION  
CALL  
(800) 245-7722**

## CENTER SUPPORT, FRONT SIDE, EXPLODED VIEW





- 450 2-6 CLUTCH BACKING PLATE SNAP RING
- 451 2-6 CLUTCH BACKING PLATE
- 452 2-6 CLUTCH FRICTION PLATES (5 REQUIRED)
- 453 2-6 CLUTCH STEEL PLATES (5 REQUIRED)
- 454 2-6 CLUTCH "WAVE" PLATE
- 455 2-6 CLUTCH "BELLVILLE" RETURN SPRING SNAP RING
- 456 2-6 CLUTCH "BELLVILLE" RETURN SPRING
- 457 2-6 CLUTCH APPLY PISTON ASSEMBLY
- 458 CENTER SUPPORT FRONT BUSHING
- 459 CENTER SUPPORT ASSEMBLY
- 460 CENTER SUPPORT REAR BUSHING

Copyright © 2007 ATSG

Figure 105

## CENTER SUPPORT, REAR SIDE, EXPLODED VIEW



- 459 CENTER SUPPORT ASSEMBLY
- 461 LOW AND REVERSE CLUTCH BACKING PLATE SNAP RING
- 462 LOW AND REVERSE CLUTCH BACKING PLATE
- 463 LOW AND REVERSE CLUTCH FRICTION PLATES
- 464 LOW AND REVERSE CLUTCH STEEL PLATES
- 465 LOW AND REVERSE CLUTCH "WAVE" PLATE
- 466 LOW AND REVERSE CLUTCH RETURN SPRING SNAP RING
- 467 LOW CLUTCH SPRAG ASSEMBLY
- 468 LOW CLUTCH SPRAG SEAL (FAT "O" RING)
- 469 LOW AND REVERSE CLUTCH "BELLVILLE" RETURN SPRING
- 470 LOW AND REVERSE CLUTCH APPLY PISTON

Copyright © 2007 ATSG

Figure 106

## COMPONENT REBUILD

### CENTER SUPPORT ASSEMBLY

1. Disassemble the center support assembly using Figure 105 and 106 as a guide.
2. Clean all center support parts thoroughly and dry with compressed air.
3. Inspect all center support parts thoroughly for any wear and/or damage.
4. Replace center support bushings as necessary, as shown in Figure 107, using the proper size bushing drivers.
5. Place the center support on a flat work surface with the front side facing up (See Figure 108).
6. Lubricate the seal surfaces of a new 2-6 clutch piston and install piston into the center support, as shown in Figure 108.
7. Install the 2-6 clutch piston "bellville" return spring onto the piston with the tabs facing down, as shown in Figure 108, and that the tabs fit between the stands on the piston.
8. Using the compression tool DT-47761 shown in Figure 108, compress the return spring and install the snap ring.

Continued on Page 67




Figure 107




Figure 108

## CENTER SUPPORT ASSEMBLY (CONT'D)

9. Install the 2-6 clutch "wave" plate into center support, as shown in Figure 109.
10. Install the 2-6 clutch plates beginning with a steel plate and alternating with a friction plate until you have installed five of each, as shown in Figure 109.
11. Install the 2-6 clutch backing plate, as shown in Figure 109.
12. Install the 2-6 clutch backing plate snap ring, as shown in Figure 109.
13. There are *no* selectives for the 2-6 clutch pack. You should have approximately .050" clutch clearance. If you do not, you have mis-built the 2-6 clutch and you must do again.
14. Ensure that the snap ring is fully seated and air check the 2-6 clutch to verify integrity, as shown in Figure 110.

Continued on Page 68




Figure 109




Figure 110

## CENTER SUPPORT ASSEMBLY (CONT'D)

15. Turn the center support over on flat surface, as shown in Figure 111.
16. Install the sprag lube seal (Fat "O" Ring), as shown in Figure 111.  
*Note: There is an installation cone available as shown in Figure 111, but is not really a mandatory tool.*
17. Lubricate the seals on a new low/reverse clutch molded piston and install into center support, as shown in Figure 112.
18. Check for proper sprag rotation, as shown in Figure 112. Low sprag should freewheel in counter-clockwise direction while holding the inner race and lock in clockwise direction.
19. Install the low sprag assembly onto the hub of the center support, as shown in Figure 112.  
*Note: Ensure the blind spline on the sprag inner race is aligned with the corresponding blind spline on center support hub. Some of the low sprags come apart with the removal of snap ring, as shown. Some low sprags come as a complete assembly and are only serviced as an assembly.*

Continued on Page 69




Figure 111




Figure 112

## CENTER SUPPORT ASSEMBLY (CONT'D)

20. Compress the low sprag assembly using the compression tool DT-47779, as shown in Figure 113.

**Note:** Ensure the compression tool contacts the sprag "outer" race and not the sprag snap ring.

21. Install **new** low sprag retaining snap ring using the installation tool, as shown in Figure 113.

**Note:** Snap ring opening must be aligned with the blind spline on the inner race, as shown in Figure 114.

22. After installation, once again verify proper low sprag rotation, as shown in Figure 115.

Continued on Page 70




Figure 114




Figure 113




Figure 115

## CENTER SUPPORT ASSEMBLY (CONT'D)

23. Install the low/reverse clutch "wave" plate, as shown in Figure 116.
24. Install the low/reverse clutch plates beginning with a steel plate and alternating with a friction plate until you have installed five of each, as shown in Figure 116.
25. Install the low/reverse clutch backing plate, as shown in Figure 116.
26. Install the low/reverse clutch backing plate snap ring, as shown in Figure 116.
27. There are **no** selectives for the low/reverse clutch pack. You should have approximately .050" clearance. If you do not, you have mis-built the low/reverse clutch and you must do it again.
28. Ensure that the snap ring is fully seated and air check the low/reverse clutch to verify integrity, as shown in Figure 117.

Continued on Page 71




Figure 116




Figure 117

## CENTER SUPPORT ASSEMBLY (CONT'D)

29. Install the 2-6 and 3-5 reverse clutch hub thrust bearing in the direction shown in Figure 118, and retain with a small amount of Trans-Jel®.
30. Set the completed center support and large case snap ring aside for final assembly.




Figure 118




Figure 119

**Component Rebuild  
Continued on Page 72**

## COMPONENT REBUILD

### 1-2-3-4 CLUTCH HUB AND SHAFT

1. Clean all 1-2-3-4 clutch hub and sun gear shaft parts thoroughly and dry with compressed air.
2. Inspect all 1-2-3-4 clutch hub and sun gear shaft parts thoroughly for any wear and/or damage.
3. Install the 4-5-6 clutch hub thrust bearing, as shown in Figure 120, and retain with a small amount of Trans-Jel®.
4. Set the 1-2-3-4 clutch hub and sun gear shaft assembly aside for final assembly.

### 2-6 AND 3-5 REVERSE CLUTCH HUB AND SHAFT

1. Clean all 2-6 and 3-5 reverse clutch hub and shaft parts thoroughly and dry with compressed air.
2. Inspect all 2-6 and 3-5 reverse clutch hub and shaft parts thoroughly for any wear and/or damage.
3. Install new bushings as necessary, as shown in Figure 121, using proper size bushing drivers.
4. Install the 1-2-3-4 clutch hub thrust bearing, as shown in Figure 121, and retain with a small amount of Trans-Jel®.
5. Set the 2-6 and 3-5 reverse clutch hub and sun gear shaft assembly aside for final assembly.

## Component Rebuild Continued on Page 73




Figure 120




Figure 121

## COMPONENT REBUILD

### REAR CARRIER AND OUTPUT SHAFT

1. Disassemble the output shaft assembly using Figure 122 as a guide.
2. Clean all output shaft parts thoroughly and dry with compressed air.
3. Inspect all output shaft parts thoroughly for any wear and/or damage. Replace as necessary.
4. There are currently three different versions of the output shaft depending on model and all 3 are illustrated and identified in Figure 123.

Continued on Page 75




Figure 122




Figure 123




Figure 124

## REAR CARRIER AND OUTPUT SHAFT (CONT'D)

5. Disassemble the rear planetary carrier using Figure 124 as a guide.
6. Remove and discard the center support roller bearing using a slide hammer, as shown in Figure 125.

*Note: Always install new roller bearing (485).*

7. After bearing removal, remove parts, as shown in Figure 124.

*Note: The last bearing is a captured bearing and is not serviced. If this bearing (491) is damaged, it will require a carrier.*

Continued on Page 76




Figure 125

## REAR CARRIER AND OUTPUT SHAFT (CONT'D)

8. Install output carrier rear sun gear, as shown in Figure 126.
9. Install rear sun gear rear thrust bearing in the direction shown in Figure 126.
10. Install the front sun gear in carrier, as shown in Figure 126.
11. Install front sun gear front thrust bearing in the direction shown in Figure 126.
12. Install a new caged roller bearing using proper driver, as shown in Figure 127, and ensure the thick side of bearing is facing up.

Continued on Page 77




Figure 126




Figure 127

## REAR CARRIER AND OUTPUT SHAFT (CONT'D)

13. Set completed rear planetary carrier assembly aside for now (See Figure 128).
  14. Install a new bushing into the output shaft, as necessary using the proper bushing driver, as shown in Figure 129.
  15. Install the output carrier rear internal ring gear with the step side facing down, as shown in Figure 129.
- Note: This is the thickest of the two internal ring gears.**
16. Install the output carrier internal ring gear spacer, as shown in Figure 129.
  17. Install the output carrier internal ring gear snap ring, as shown in Figure 129, and ensure that it is fully seated.

Continued on Page 78





Figure 128



- 494 RETAINING SNAP RING (2 REQUIRED)
- 496 OUTPUT CARRIER INTERNAL RING GEAR SPACER
- 497 OUTPUT CARRIER REAR INTERNAL RING GEAR
- 498 OUTPUT SHAFT BUSHING
- 499 OUTPUT SHAFT ASSEMBLY (MODEL SENSITIVE)

Figure 129

## REAR CARRIER AND OUTPUT SHAFT (CONT'D)

18. Place the pre-assembled rear planetary carrier assembly on flat work surface with the snap ring side facing down, as shown in Figure 130.
  19. Install the output carrier to output shaft thrust bearing onto carrier in the direction shown in Figure 130.
  20. Install the output carrier front internal ring gear onto the carrier with the stepped side facing up, as shown in Figure 130, and engage it with the bottom set of carrier pinion gears.
- Note: Should look like the illustration shown in Figure 131.**
21. Install output shaft assembly over the output carrier, as shown in Figure 131.

Continued on Page 79




Figure 130




Figure 131

## REAR CARRIER AND OUTPUT SHAFT (CONT'D)

22. Turn the entire output carrier and output shaft assembly over and install the last retaining snap ring, as shown in Figure 132.
23. Install the DT-47786 lifting tool into the completed output shaft assembly, as shown in Figure 133, and set aside for final assembly.

**Component Rebuild  
Continued on Page 80**




Figure 132




Figure 133





Figure 134

## SOLENOID BODY AND VALVE BODY ASSEMBLY EXPLODED VIEW



- 301 Bolt, M5 X 36mm.
- 302 Bolt, M6 X 20mm.
- 303 Input and Output Speed Sensor Assembly.
- 304 Upper Valve Body Assembly.
- 305 Valve Body Spacer Plate Assembly (With Gasket).
- 306 Valve Body Check Balls (7 Required).
- 307 Lower Valve Body Assembly.
- 308 Internal Mode Switch Assembly.
- 309 Bolt, M5 X 45mm.
- 310 Bolt, M5 X 55mm.
- 311 Filter Plate Assembly.
- 312 Bolt, M5 X 53mm.
- 314 Control Solenoid Body And TCM Assembly.
- 315 Internal Mode Switch Wire Harness Clip.
- 316 Speed Sensor Wire Harness Clip (2 Required).

Figure 135

## COMPONENT REBUILD VALVE/SOLENOID BODY ASSEMBLY

1. Remove the input and output speed sensor assembly by removing the retaining bolts on each sensor, as shown in Figure 136.
2. Disconnect Mode Switch electrical connector from the solenoid body/TCM, as shown in Figure 137.
3. Remove the internal mode switch assembly, as shown in Figure 137.
4. Remove the remaining bolts that retain the Solenoid Body/TCM assembly to the valve body, as shown in Figure 138, and remove the Solenoid Body/TCM assembly.
5. Remove and discard the gasket and screen assembly, as shown in Figure 138.

Continued on Page 82




Figure 137




Figure 136




Figure 138





Figure 139

## VALVE/SOLENOID BODY ASSEMBLY (CONT'D)

6. Remove the remaining bolts retaining lower and upper valve bodies and separate the two, as shown in Figure 139.
7. Remove and discard the spacer plate/gasket assembly. Gasket is bonded to the plate.  
*Note: GM recommends replacement of spacer plate on all rebuilds.*
8. Disassemble the lower valve body assembly using Figure 140 as a guide.
9. Lay each valve line-up out in order as you remove them from the valve body casting.
10. Inspect each valve, valve spring, bore plugs and retainers for any wear and/or damage.
11. Clean all lower valve body parts thoroughly and dry with compressed air.
12. Install each valve train back into their bores *exactly*, as shown in Figure 140, lubricating them with Dexron VI® as they are installed.

Continued on Page 83



- 323 VALVE LINE-UP RETAINER (4 REQUIRED).
- 351 LOWER VALVE BODY CASTING.
- 352 CLUTCH SELECT VALVE 3.
- 353 CLUTCH SELECT VALVE 3 SPRING.
- 354 CLUTCH SELECT VALVE 3 BORE PLUG.
- 355 CLUTCH SELECT VALVE 2 SPRING.
- 356 CLUTCH SELECT VALVE 2 BORE PLUG.

- 358 MANUAL VALVE.
- 359 TCC REGULATOR VALVE SPRING.
- 360 TCC REGULATOR VALVE.
- 361 TCC REGULATOR SHUTTLE VALVE.
- 362 TCC REGULATOR VALVE BORE PLUG.
- 363 COMPENSATOR FEED REGULATOR VALVE SPRING.
- 364 COMPENSATOR FEED REGULATOR VALVE.

Copyright © 2007 ATSG

Figure 140

## VALVE/SOLENOID BODY ASSEMBLY (CONT'D)

13. Disassemble the upper valve body assembly using Figure 141 as a guide.

**Special Note: "Do Not" remove the clutch piston backfill blow-off plug, spring, or ball. The bore plug is pressed in to a precise depth. Refer to Figure 141 for location in the upper valve body assembly.**

14. Lay each valve line-up out in order as you remove them from the valve body casting.

15. Inspect each valve, valve spring, bore plugs and retainers for any wear and/or damage.

16. Clean all upper valve body parts thoroughly and dry with compressed air.

17. Install each valve train back into their bores **exactly**, as shown in Figure 141, lubricating them with Dexron VI® as they are installed.

Continued on Page 84




Figure 141

## VALVE/SOLENOID BODY ASSEMBLY (CONT'D)

18. Install the seven (7) checkballs in their proper locations in the upper valve body, as shown in Figure 142.
19. Install the valve body locating dowels in the upper valve body, as shown in Figure 141.
20. Install a *new* spacer plate and gasket assembly over locating dowels, as shown in Figure 143.  
**Note: GM recommends the spacer plate be replaced on all rebuilds because of gaskets being bonded to spacer plate.**
21. Install the lower valve body over the locating dowels and on top of the spacer plate, as shown in Figure 143.

22. Turn the complete assembly over and install 12 valve body bolts, 36mm in length, in locations shown in Figure 144.

Continued on Page 85





Figure 142



- 301 VALVE BODY BOLT M5 X 36MM (12 REQUIRED)
- 304 UPPER VALVE BODY ASSEMBLY
- 305 VALVE BODY SPACER PLATE ASSEMBLY (WITH GASKETS)
- 306 VALVE BODY CHECKBALLS (7 REQUIRED)
- 307 LOWER VALVE BODY ASSEMBLY

Figure 143

## VALVE/SOLENOID BODY ASSEMBLY (CONT'D)

23. Torque the 12 upper valve body to lower valve body bolts to 8 N·m (71 in.lb.), using the sequence shown in Figure 144.
24. Install a **new** filter plate and gasket (311) on Solenoid Body/TCM assembly, as shown in Figure 145, ensuring that it goes over locating dowels and snaps into place.
25. Install the Solenoid Body/TCM onto the valve body and start the two attaching bolts through the side, as shown in Figure 146, and hand tighten only at this time.

**Note:** Solenoid Body/TCM assembly must be aligned with the locating dowel, as shown in Figure 146.

Continued on Page 86




Figure 145




Figure 144




Figure 146




Figure 147

### VALVE/SOLENOID BODY ASSEMBLY (CONT'D)

26. Install the nine (9) 55mm length valve body bolts in the locations shown in Figure 147, and hand tighten only at this time.
27. Install the six (6) 45mm length valve body bolts in the locations shown in Figure 147, and hand tighten only at this time.
28. Install the manual shift Internal Mode Switch, as shown in Figure 148, using only one 55mm long valve body bolt in the location shown and hand tighten only at this time.  
*Note: Align the switch activator slide with the manual valve, as shown in Figure 148.*
29. Connect and lock the internal mode switch electrical connector to Solenoid Body/TCM.

Continued on Page 87




Figure 148




Figure 149

### VALVE/SOLENOID BODY ASSEMBLY (CONT'D)

30. Now you can torque all 18 valve body bolts to 8 N·m (71 in.lb.), in the sequence shown in Figure 149.  
*Note: Bolt torque sequencing is critical to the proper function on this unit.*
31. The two 53mm bolts going in the side of the Solenoid Body/TCM (17 and 18) in Figure 149 **must** be tightened last.
32. Inspect the contact area between the "heat sink" area of the Solenoid Body/TCM assembly and valve body assembly, as shown in Figure 150.
33. There should be no visible gap. If a gap exists, loosen all 18 bolts and retighten in the required sequence, as shown in Figure 149.  
*Note: The six empty holes left in the assembly are for the 70mm long bolts that retain the valve body assembly to the case.*




Figure 150

Continued on Page 88

## VALVE/SOLENOID BODY ASSEMBLY (CONT'D)

34. Install input and output speed sensor assembly, as shown in Figure 151, and torque retaining bolts to 12 N·m (106 in.lb.).
35. Plug the speed sensor wire harness into TCM, as shown in Figure 151.
36. Set the completed Valve Body and Solenoid Body/TCM assembly aside for final assembly.




Figure 151

## COMPONENT REBUILD

### EXTENSION HOUSING

1. Install a new metal clad seal into the extension housing, as shown in Figure 152, using proper seal driver.
2. Notice that seal is driven in on the side that goes against the case.  
*Note: Corvette version is illustrated, 2WD version is also shown in Figure 152.*
3. Set completed extension housing aside for the final assembly process.




Figure 152

## FINAL ASSEMBLY

### INTERNAL COMPONENTS

1. Rotate transmission case in fixture so that rear of preassembled case is facing up, as shown in Figure 153.
2. Lubricate rear case bushing and rear seal inside diameters with a small amount of Trans-Jel®, as shown Figure 153.
3. Install the output shaft to case thrust bearing into case, in the direction shown in Figure 154.
4. Ensure the DT-47786 lifting tool is completely threaded into the output shaft assembly, as shown in Figure 154. Due to the weight of the assembly, incomplete threading may let the assembly break free, causing damage/injury.
5. Install the pre-assembled output shaft assembly into the case, as shown in Figure 154, using the DT-47786 lifting tool.

Continued on Page 90




Figure 153




Figure 154

## FINAL ASSEMBLY

### INTERNAL COMPONENTS (CONT'D)

6. Install the pre-assembled center support assembly, as shown in Figure 155.
7. When the center support assembly is properly installed, the fluid passages should align with the fluid passage seal bores in the case.
 

*Note: It may be necessary to rotate the output shaft by hand in order to fully seat the center support in the case.*
8. Install center support retaining ring with the tapered side facing up, as shown in Figure 155, and snap ring opening at the 9 o'clock position, using the J-45126 snap ring pliers along with DT-47773 adapter set, shown in Figure 156.
 

*Note: This is a mandatory tool for snap ring installation to prevent bodily injury.*
9. Install the thrust bearing on top of the center support in direction shown in Figure 157.
10. Install the 2-6 and 3-5 reverse clutch hub and shaft assembly, as shown in Figure 157.




Figure 156

Continued on Page 91




Figure 155




Figure 157

## FINAL ASSEMBLY

### INTERNAL COMPONENTS (CONT'D)

11. Install the 1-2-3-4 clutch hub thrust bearing in direction shown in Figure 158.
12. Install 1-2-3-4 clutch hub and shaft assembly, as shown in Figure 158.
13. Install 4-5-6 clutch hub to shell thrust bearing in direction shown in Figure 158.
14. Install 4-5-6 clutch hub and the dampener assembly, as shown in Figure 159.
15. Install the 4-5-6 clutch hub to turbine shaft thrust bearing in direction shown in Figure 159.

Continued on Page 92




Figure 158




Figure 159

## FINAL ASSEMBLY

### INTERNAL COMPONENTS (CONT'D)

16. Install the input sun gear thrust bearing into the 4-5-6 clutch housing in the direction shown in Figure 160.
17. Install the input carrier thrust washer onto back side of carrier, as shown in Figure 161, and retain with a small amount of Trans-Jel®.
18. Install the input planetary carrier and thrust washer assembly into the ring gear, as shown in Figure 161, with a rotating motion.

Continued on Page 93




Figure 160




Figure 161

## **FINAL ASSEMBLY**

### **INTERNAL COMPONENTS (CONT'D)**

19. Install input sun gear, as shown in Figure 162, with a rotating motion until fully seated.
20. Install the 4-5-6 clutch housing assembly with carrier and sun gear into the case, as shown in Figure 163.
21. Rotate the turbine shaft back and forth until all 4-5-6 clutch plates have engaged on the 4-5-6 clutch hub and dampner assembly.

Continued on Page 94




Figure 162




Figure 163

## FINAL ASSEMBLY

### INTERNAL COMPONENTS (CONT'D)

22. Place the completed 1-2-3-4 and 3-5 reverse clutch housing on a flat surface, as shown in Figure 164.
  23. Install the DT-47781 clutch assembly installer over 1-2-3-4 and 3-5 reverse clutch housing, as shown in Figure 164, and close the vise grip type clamp.
- Note: This tool is also a suggested purchase as there are three different things to align by rotating back and forth to install this housing.*
24. Grab the entire assembly by the "handles" of the DT-47781 and install the 1-2-3-4 and 3-5 reverse clutch housing, as shown in Figure 165.
  25. Wiggle the DT-47781 back and forth in order to align the 1-2-3-4 clutch plates, and the 3-5 reverse clutch plates with the external splines of the two shells. (See Figure 165).
  26. There are also splines on the 3-5 reverse clutch housing that must be engaged into the splines of the input carrier.
  27. To verify that 1-2-3-4 and 3-5 reverse clutch housing is fully seated, lift up on the turbine shaft. There should not be any noticeable end-play..

Continued on Page 95




Figure 164




Figure 165

## FINAL ASSEMBLY

### INTERNAL COMPONENTS (CONT'D)

28. Lay the completed converter housing and oil pump assembly on flat work surface, as shown in Figure 166.
  29. Install new converter housing to case "O" ring seal, as shown in Figure 166, and lube with a small amount of Trans-Jel®.
  30. Install the converter housing and oil pump assembly, as shown in Figure 167.
- Note: You may have to turn the turbine shaft to get the assembly to fully seat, as the stator shaft must spline into the input sun gear.**
31. Ensure that converter housing is fully seated against case surface and over locating dowel
  32. Install the nine (9) converter housing to case retaining bolts, as shown in Figure 167, finger tight only at this time.

Continued on Page 96




Figure 166






Figure 167

**TORQUE CONVERTER HOUSING BOLTS  
TO 72 N·M (53 FT.LB.)**



Copyright © 2007 ATSG

Figure 168



Copyright © 2007 ATSG


Figure 169

**FINAL ASSEMBLY**

**INTERNAL COMPONENTS (CONT'D)**

33. Torque all nine converter housing bolts down to 72 N·m (53 ft.lb.), as shown in Figure 168, using a criss-cross pattern from side to side.
34. Install a new turbine shaft "O" ring seal in the groove, as shown in Figure 169, using a small screwdriver.
35. Rotate the transmission in fixture so that pan surface is facing up, as shown in Figure 170.
36. Lubricate with small amount of Trans-Jel® and install the three valve body seals into the bores in the bottom of valve body (See Figure 170).
37. Install the pre-assembled valve body onto the case, as shown in Figure 170, ensuring the manual valve is engaged on the detent lever pin, as shown in Figure 171.
38. Install the six 70mm valve body to case bolts in the locations shown in Figure 171.

Continued on Page 97



18 VALVE BODY TO OIL PUMP SEAL ASSEMBLY  
19 VALVE BODY TO OIL PUMP SEAL ASSEMBLY  
20 VALVE BODY TO CENTER SUPPORT SEAL ASSEMBLY

Figure 170




Figure 171

## FINAL ASSEMBLY

### INTERNAL COMPONENTS (CONT'D)

39. If not already done, install new filter seal into oil pump bore, as shown in Figure 172, using the proper seal driver.
40. Install a new oil filter assembly, as shown in Figure 172.
41. Install the detent spring and roller, as shown in Figure 172, torque bolt to 12 N·m (106 in.lb.).  
*Note: Ensure roller is centered over inside detent lever.*

Continued on Page 98




Figure 172




Figure 173




Figure 174

### INTERNAL COMPONENTS (CONT'D)

42. Install two new "O" rings into the grooves in the connector sleeve, as shown in Figure 173, and lubricate with small amount of Trans-Jel®.
43. Install a new "lip" seal into the groove in the connector sleeve, as shown in Figure 173, and lubricate with small amount of Trans-Jel®.
44. Orientate the alignment tab inside the passage sleeve, with corresponding slot of the Solenoid Body/TCM assembly, and lift up the connector slide lock to allow the sleeve to be installed.
45. Push the sleeve straight into the case bore and TCM connector. **Do Not**, rotate the sleeve at any time (See Figure 175).
46. When the sleeve is properly installed, the distance from the case surface to the end of the sleeve should be 14-16mm (.551" - .630"), as shown in Figure 175.
47. Ensure the sleeve is fully seated and push down on the electrical connector slide lock, as shown in Figure 175, to lock the connector sleeve in place.
48. There is a special tool available to remove and install the electrical connector sleeve, as shown in Figure 174.

Continued on Page 99




Figure 175

## INTERNAL COMPONENTS (CONT'D)

49. Install a new bottom oil pan gasket, as shown in Figure 176.  
*Note: Oil pan gasket is reuseable as long as none of the beads are broken. Experience shows it should get a new one.*
50. Install the bottom oil pan assembly, as shown in Figure 176, and install the 18 pan bolts.
51. Torque all of the bottom oil pan bolts down to 9 N·m (80 in.lb.), using a criss-cross pattern.
52. Install the extension housing studs, if they were removed, as shown in Figure 177.
53. Install the case extension housing, as shown in Figure 177, and the six retaining bolts.
54. Torque bolts to 50 N·m (37 ft.lb.).

Continued on Page 100




Figure 176




Figure 177




Figure 178

### **INTERNAL COMPONENTS (CONT'D)**

55. Lubricate the torque converter hub with small amount of Trans-Jel®.
56. Install the torque converter onto transmission, with a rotating motion until fully engaged with the splines and the oil pump rotor, as shown in Figure 178.
57. Remove transmission from bench fixture and remove holding fixture and adapter, as shown in Figure 179.

**CONGRATULATIONS  
YOU ARE FINISHED!**












Figure 179

## 6L80 BOLT CHART FOR IDENTIFICATION

| "A"   | "B"   | "C"   | "D"   | "E"  | "F"   | "G"   | "H"   |
|---|---|---|---|--|---|---|---|
| 7 mm Head   | 7 mm Head   | 7 mm Head   | 7 mm Head   | 7 mm Head  | 8 mm Head   | 8 mm Head   | 8 mm Head   |
|    |    |  |  |   |    |    |  |
|    |    |  |  |  |    |    |  |
| Lower VB To Upper VB (12) (36mm)  | Upper VB To Lower VB (10) (45mm)  | Sol Body/TCM To Upper VB (2) (53mm)   | Upper VB To Lower VB (6) (55mm)   | VB To Case (6) (70mm)  | Speed Sensor (2) (20mm)   | Pump Stator To Pump Cover (6) (20mm)  | Detent Spring (1) (16mm)  |
| "J"   | "K"   |   |   |  | "L"   | "M"   |   |
| 10 mm Head  | 10 mm Head  |   |   |  | 15 mm Head  | 15 mm Head  |   |
|  |  |   |   |  |  |  |   |
|  |  |   |   |  |  |  |   |
| Oil Pan to Case (18) (20mm)   | Pump Cover To Pump Body (13) (40mm)   |   |   |  | Bell Housing To Case (9) (50mm)   | Ext. Housing To Case (6) (40mm)   |   |











| <b>SPECIAL TOOLS AND EQUIPMENT</b>  |   |  |   |
|---|---|--|---|
| <b>Illustration</b>   | <b>Tool Number/Description</b>  | <b>Illustration</b>  | <b>Tool Number/Description</b>                          |
|    | DT 47605<br>Holding Fixture Adapter                                     |    | DT 47768-3<br>Seal Sizer                                |
|    | DT 47715<br>Electrical Connector<br>Passage Sleeve<br>Remover/Installer |    | DT 47770<br>Seal Installer                              |
|  | DT 47761<br>Clutch Spring Compressor                                    |   | DT 47773<br>Snap Ring Pliers Adapter Set                |
|  | DT 47768-1<br>Seal Protector  |  | DT 47778-1<br>Low Clutch Sprag Retaining<br>Ring Cone   |
|  | DT 47768-2<br>Seal Pusher   |  | DT 47778-2<br>Low Clutch Sprag Retaining<br>Ring Pusher |

Figure 181











| <b>SPECIAL TOOLS AND EQUIPMENT</b>  |   |  |   |
|---|---|--|---|
| <b>Illustration</b>   | <b>Tool Number/Description</b>                      | <b>Illustration</b>  | <b>Tool Number/Description</b>                |
|    | DT 47779<br>Clutch Spring Compressor                |    | DT 47786<br>Output Carrier/Shaft Lifting Tool |
|    | DT 47780<br>Low Clutch Sprag Seal Cone              |    | DT 47848<br>Seal Installer                    |
|   | DT 47781<br>C1234 and 35R Clutch Assembly Installer |   | DT 47857<br>Bearing Installer                 |
|  | DT 47782-1<br>Retaining Ring Cone                   |  | DT 47865<br>Bearing Remover                   |
|  | DT 47782-2<br>Retaining Ring Installer              |  | DT 47866<br>Bearing Installer                 |

Figure 182









| <b>SPECIAL TOOLS AND EQUIPMENT</b>   |  |   |  |
|--|--|---|--|
| <b>Illustration</b>  |  | <b>Tool Number/Description</b>                  |  |
|     |  | DT 47867<br>Adjustable Clutch Spring Compressor |  |
|     |  | DT 47868-1<br>Pack Travel Weight                |  |
|    |  | DT 47868-2<br>Magnetic Base Adapter             |  |
|   |  | J 3289-20<br>Holding Fixture Base Assembly      |  |
|   |  | J 46664<br>Pump Cover Alignment Tool            |  |
|    |  | J 6125-B<br>Slide Hammer                        |  |
|    |  | J 8001<br>Dial Indicator Set                    |  |
|   |  | J 8092<br>Driver Handle                         |  |
|  |  | J 8763-B<br>Holding Fixture                     |  |
|  |  | J 23129<br>Universal Seal Remover               |  |

Figure 183










| <b>SPECIAL TOOLS AND EQUIPMENT</b>  |   |  |                                     |
|---|---|--|-------------------------------------|
| <b>Illustration</b>   | <b>Tool Number/Description</b>                    | <b>Illustration</b>  | <b>Tool Number/Description</b>      |
|    | J 26900-13<br>Magnetic Base                       |    | J 45000<br>Seal Remover             |
|    | J 38693<br>Seal Installer                         |    | J 45124<br>Remover Bridge           |
|   | J 38734<br>Intermediate Spring Compressor Adapter |   | J 45126<br>Snap Ring Pliers         |
|  | J 42183<br>Driver Handle                          |  | J 45201<br>Cooler Line Seal Remover |
|  | J 43074<br>Clutch Spring Compressor               |  |                                     |

Figure 184



# Technical Service Information

| <i>6L80 Transmission General Specifications</i> |                           |
|---|---------------------------|
| <b>RPO Codes</b>                                | <b>MYC</b>                |
| <b>Production Location</b>                      | <b>Ypsilanti MI (USA)</b> |
| <b>Transmission Drive</b>                       | <b>Rear Wheel Drive</b>   |
| <b>1st Gear Ratio</b>                           | <b>4.027</b>              |
| <b>2nd Gear Ratio</b>                           | <b>2.364</b>              |
| <b>3rd Gear Ratio</b>                           | <b>1.532</b>              |
| <b>4th Gear Ratio</b>                           | <b>1.152</b>              |
| <b>5th Gear Ratio</b>                           | <b>0.852</b>              |
| <b>6th Gear Ratio</b>                           | <b>0.667</b>              |
| <b>Reverse Gear Ratio</b>                       | <b>3.064</b>              |
| <b>Torque Converter Size</b>                    | <b>258/300 mm</b>         |
| <b>Pressure Taps</b>                            | <b>Line Pressure</b>      |
| <b>Fluid Type</b>                               | <b>Dexron VI®</b>         |
| <b>Case Material</b>                            | <b>Cast Aluminum</b>      |
| <b>6L80 Net Weight</b>                          | <b>100kg (220 lb.)</b>    |

| <i>6L80 Pump Selective Specifications</i>   |                |                 |
|---|----------------|-----------------|
| <b>Important</b>  |                |                 |
| Rotor and slide must be chosen from the same size classification as the oil pump body.<br>Allowable rotor and slide to oil pump body end play   |                |                 |
| Slide to Pump Body Face<br>0.020-0.051 mm (0.0008-0.0020 in.)   |                |                 |
| Rotor to Pump Body Face<br>0.020-0.038mm (0.0008-0.0015 in.)  |                |                 |
| The oil pump assembly has "selective" rotor and slide components. These components are chosen based on pump body dimensions. Oil pump rotor and slide components are available in three size classifications (1, 2, 3) with the following tolerances. |                |                 |
| <b>PUMP POCKET DEPTH</b>  |                |                 |
| SIZE CLASSIFICATION   | THICKNESS (MM) | THICKNESS (IN)  |
| 1   | 17.980-17.994  | .7079" - .7084" |
| 2   | 17.994-18.007  | .7084" - .7089" |
| 3   | 18.007-18.003  | .7089" - .7100" |
| <b>ROTOR SELECTION</b>  |                |                 |
| ROTOR SELECTION   | THICKNESS (MM) | THICKNESS (IN)  |
| 1   | 17.948-17.961  | .7066" - .7071" |
| 2   | 17.961-17.974  | .7071" - .7076" |
| 3   | 17.974-17.987  | .7076" - .7081" |
| <b>SLIDE SELECTION</b>  |                |                 |
| SLIDE SELECTION   | THICKNESS (MM) | THICKNESS (IN)  |
| 1   | 17.948-17.961  | .7066" - .7071" |
| 2   | 17.961-17.974  | .7071" - .7076" |
| 3   | 17.974-17.987  | .7076" - .7081" |

## **CLUTCH BACKING PLATE RETAINING RING SPECIFICATIONS**

| <b>1-2-3-4 CLUTCH</b>       |            |
|-----------------------------|------------|
| THICKNESS                   | O.D. COLOR |
| 2.15-2.25mm (.085" - .089") | YELLOW     |
| 2.42-2.52mm (.095" - .099") | NONE       |
| 2.69-2.79mm (.106" - .110") | PURPLE     |
| 2.96-3.06mm (.117" - .120") | LIGHT BLUE |
| 3.23-3.33mm (.127" - .131") | ORANGE     |

| <b>3-5 REVERSE CLUTCH</b>   |             |
|-----------------------------|-------------|
| THICKNESS                   | O.D. COLOR  |
|                             | GRAY        |
| 1.88-1.98mm (.074" - .078") | LIGHT GREEN |
| 2.15-2.25mm (.085" - .089") | YELLOW      |
| 2.42-2.52mm (.095" - .099") | NONE        |
| 2.69-2.79mm (.106" - .110") | PURPLE      |

| <b>4-5-6 CLUTCH</b>         |            |
|-----------------------------|------------|
| THICKNESS                   | O.D. COLOR |
| 1.61-1.71mm (.063" - .067") | YELLOW     |
| 2.02-2.12mm (.080" - .083") | NONE       |
| 2.44-2.54mm (.096" - .100") | PURPLE     |


**Important:** After measuring clutch pack travel, determine if the measurement is within the specification. If the measurement is not within the specification, measure the thickness of the existing snap ring, and then choose a thicker or thinner snap ring that will bring the measurement within specification.

Copyright © 2007 ATSG

Figure 185

## LINE PRESSURE SPECIFICATIONS

*Line Pressure Tap is located in the converter housing on the right hand side as shown below.*



*Normal line pressure should be 50-53 PSI, when in Park or Neutral and RPM below 1500, and then should rise smoothly with throttle opening when in gear and road testing. Amount of line rise will depend on engine load and vehicle speed.*

## FLUID FILL PROCEDURE

*Perform this procedure for vehicles that are not equipped with a fill tube and dipstick.*

1. Unlock the fill tube plug by lifting up on the plunger. Once the plunger is lifted, remove the entire plug assembly, as shown above.  
*Note: You may want to purchase an extra dipstick tube to assist in filling this unit.*
2. Fill unit only with the appropriate amount of Dexron VI® fluid needed to fill the unit based on the type of repair performed. See capacity chart below.
3. Since the Corvette unit is not equipped with a fill tube and dipstick, a tube in the bottom pan is used to set the fluid level, much like some Ford transmissions.

4. Raise the vehicle on a hoist. The vehicle must be level, with the engine running and the shift lever in the PARK position. Allow the engine to idle for at least a minute.
5. The engine **must** be running when the fluid level control plug in bottom pan is removed or excessive fluid loss will occur, resulting in an under-filled condition.
6. If the fluid is flowing as a steady stream, wait until the fluid begins to drip.
7. If no fluid comes out, add fluid until the fluid drips out and reinstall fluid level control plug in bottom pan.

| <b>DEXRON VI®</b> | <b>TRANSMISSION FLUID REQUIREMENTS</b>                      | <b>DEXRON VI®</b>  |
|-------------------|---|--------------------|
|                   | <b>Pan Removal - Approximate Capacity</b>                   | <b>6.5 Quarts</b>  |
|                   | <b>Overhaul - Approximate Capacity (Cadillac STSV/XLRV)</b> | <b>10 Quarts</b>   |
|                   | <b>Overhaul - Approximate Capacity (Corvette)</b>           | <b>12.5 Quarts</b> |

Copyright © 2007 ATSG

Figure 186



# Technical Service Information

| <b>TORQUE SPECIFICATIONS</b>   |                |                 |             |                      |                |
|--|----------------|-----------------|-------------|----------------------|----------------|
| <b>Application</b>   | <b>Ref No.</b> | <b>Quantity</b> | <b>Size</b> | <b>Specification</b> |                |
|  |                |                 |             | <b>Metric</b>        | <b>English</b> |
| Case Extension Stud to Case Extension  | 17             | 2               | M10x1.5     | 15 N-m               | 11 lb ft       |
| Case Extension to Case Assembly  | 16             | 6               | M10x1.5x40  | 50 N-m               | 37 lb ft       |
| Control Solenoid Valve Assembly and Control Valve Lower Body Assembly to Control Valve Upper Body Assembly | 310            | 6               | M5x0.8x55   | 8 N-m                | 71 lb in       |
| Control Solenoid Valve Assembly and Control Valve Lower Body Assembly to Control Valve Upper Body Assembly | 309            | 10              | M5x0.8x45   | 8 N-m                | 71 lb in       |
| Control Solenoid Valve Heat Sink to Valve Body   | 312            | 2               | M5x0.8x53   | 8 N-m                | 71 lb in       |
| Control Valve Upper Body Assembly to Control Valve Lower Body Assembly                                     | 301            | 12              | M5x0.8x36   | 8 N-m                | 71 lb in       |
| Control (with Body and Valve) Valve Assembly to Case Assembly  | 22             | 6               | M5x0.8x73   | 8 N-m                | 71 lb in       |
| Fluid Pan Assembly to Case Assembly  | 30             | 18              | M6x1.0x20   | 9 N-m                | 80 lb in       |
| Trans Oil Level Check Plug to Fluid Pan Assembly   | 31             | 1               | M12x1.75    | 25 N-m               | 18 lb ft       |
| Fluid Pump Cover Assembly to Torque Converter Housing  | 231            | 13              | M6 1.0x40   | 11 N-m               | 97 lb in       |
| Input and Output Speed Sensor Assembly to Control Valve Upper Body Assembly                                | 302            | 2               | M6x1.0x20   | 12 N-m               | 106 lb in      |
| Line Pressure Test Hole Plug to Torque Converter Housing   | 202            | 1               | 1/8-27 NPTF | 11 N-m               | 97 lb in       |
| Manual Shaft Detent Assembly to Valve Body   | 23             | 1               | M6x1.0x14.5 | 12 N-m               | 106 lb in      |
| Torque Converter Housing Assembly to Case Assembly   | 3              | 9               | M10x1.5x50  | 72 N-m               | 53 lb ft       |
| *Reference number refers to the component callout number in Disassembled Views                             |                |                 |             |                      |                |

Copyright © 2007 ATSG

Figure 187